ZENOAH®

# PARTS LIST

# BRUSHCUTTERS

# BC4501LE
# BC4501WE

**NOTE:**

1. Use HUSQVARNA ZENOAH genuine parts as specified in the parts list for repair and/or replacement.
2. HUSQVARNA ZENOAH does not warrant the machines, which have been damaged by the use of any parts other than those specified by the company.
3. When placing parts orders for repair and/or replacement, check if the model name and the serial number are applicable to those specified in the parts list, then use parts number described in the parts list.
4. The contents described in the parts list are accurate as of the date and may change due to improvement.
5. The parts for the machine shall be supplied ten (10) years after the machine is discontinued. [It is possible that some specific parts may be subject to change of their delivery term and list price within the limit of ten (10) years after the machine is discontinued. It is also possible that some parts may be available even after the limit of ten (10) years.]

Fig.1 CUTTER GROUP LE ..... 2
Fig.2 CUTTER GROUP WE ..... 4
Fig.3 ENGINE GROUP ..... 4

APPLICABLE SERIAL NUMBERS:


APPLICABLE SERIAL NUMBERS:

71000101 and up

January 2018

**BC4501LE**

Fig.1 CUTTER GROUP




# Fig.1 CUTTER GROUP

| Key# | PART NUMBER | DESCRIPTION | Q'ty /UNIT | NOTE |
|---|---|---|---|---|
| 1 | 4050-11110 | HOUSING | 1 | |
| 2 | 4050-11150 | CAP | 1 | |
| 3 | T3042-11210 | JOINT | 1 | |
| 4 | 4050-11250 | ABSORBER-F | 1 | |
| 5 | 4050-11260 | ABSORBER-R | 1 | |
| 6 | 4820-21310 | BOLT T27 | 4 | M5xL30 |
| 7 | T4950-63040 | BOLT T27 | 1 | M6xL30 |
| 8 | 4820-12350 | BOLT T27 | 1 | M5xL10 |
| 9 | 591 42 58-01 | DRUM | 1 | |
| 10 | 06004-06202 | BEARING | 1 | |
| 11 | 04065-03515 | RING | 1 | |
| 12 | 04064-01510 | RING | 1 | |
| 13 | T4950-62040 | BOLT T27 | 4 | M6xL20 |
| | | | | |
| 20 | T3042-12100 | PIPE COMP. | 1 | 1500x28xT2 |
| | | | | |
| 23 | 6340-12211 | SHAFT, spline $\phi$ 8x9tooth | 1 | 1540x8 |
| | | | | |
| 28 | 848JJ76100 | GEARCASE ASSY | 1 | |
| 29 | 848JL061A2 | • GEARCASE | 1 | |
| 30 | 06000-06001 | • BEARING | 1 | |
| 31 | 06001-06001 | • BEARING | 1 | |
| 33 | 04065-02812 | • RING | 1 | |
| 34 | 8488AL3500 | • SEAL | 1 | |
| 35 | 848JJ761B0 | • SHAFT | 1 | |
| 36 | 848JL061C3 | • GEAR | 1 | |
| 37 | T4950-60800 | • BOLT TORX T27 | 1 | M6xL8 |
| 38 | T4950-40800 | • BOLT TORX T27 | 1 | M4xL8 |
| 39 | 848JJ761D1 | • PINION | 1 | |
| 40 | 06000-06000 | • BEARING | 1 | |
| 41 | 06004-06202 | • BEARING | 1 | |
| | | | | |
| 43 | 04065-03515 | • RING, SNAP | 1 | |
| 44 | 04064-01210 | • RING | 1 | |
| 45 | T4950-63540 | • BOLT TORX | 1 | |
| 46 | 848JL061F4 | • HOLDER (A) | 1 | |
| 47 | 848JL061L0 | • PLATE | 1 | |
| 48 | 848JL061G2 | • HOLDER (B) | 1 | |
| 49 | T3002-13260 | • NUT | 1 | M10xP1.25 |
| | | | | |
| 52 | T1501-32120 | • BOLT TORX T27 | 1 | M5xL12 |
| 53 | 848JL066C3 | PLATE | 1 | |
| | | | | |
| 80 | 848JL23812 | HANGER ASSY | | |
| | | • HANGER | 1 | |
| | | • CLAMP | | |
| 83 | 4820-13180 | • BOLT TORX T27 | 1 | M5xL20 |
| | | | | |
| 90 | 848JJ890R0 | PLATE NAME | 1 | |
| 91 | 8488X10020 | PLATE | 1 | |
| 92 | T3114-14000 | HANDLE ASSY | 1 | |
| 93 | 0263-90530 | • SCREW | 4 | |

| Key# | PART NUMBER | DESCRIPTION | Q'ty /UNIT | NOTE |
|---|---|---|---|---|
| 120 | 573 97 65-01 | GRIP ASSY | 1 | |
| 121 | 573 97 68-01 | • BODY-R | 1 | |
| 122 | 573 97 69-01 | • BODY-L | 1 | |
| 123 | 573 97 71-01 | • LEVER | 1 | |
| 124 | 848JL233D3 | • SPRING | 1 | |
| 125 | 848JL233E2 | • LEVER-S | 1 | |
| 126 | 848JL233F3 | • SPRING | 1 | |
| 127 | T4506-52110 | • SWITCH | 1 | |
| 128 | 8488251601 | • SCREW T27 | 4 | TP5(P-tight)xL16 |
| 129 | 4820-13180 | • BOLT TORX T27 | 2 | M5xL20 |
| 130 | 573 97 70-01 | • LEVER | 1 | |
| 131 | 848JL233H3 | • ABSORBER | 4 | |
| 132 | 848JL233K3 | • HOLDER REAR | 1 | |
| 133 | 848JL233J2 | • HOLDER FRONT | 1 | |
| 134 | 574 27 03-01 | • CABLE COMP. | 1 | |
| 135 | 8488M10070 | • CORD COMP., BLACK | 1 | CA104 |
| 136 | 6420-14511 | • TUBE | 1 | |
| 137 | 8488M10660 | • CORD COMP., RED | 1 | CB104 |
| | | | | |
| 159 | 6220-17202 | HARNESS ASSY | 1 | |
| | | | | |
| 161 | 8488U00210 | TOOL SET | 1 | |
| 162 | 09007-00425 | • WRENCH | 1 | |
| 163 | 8488U10050 | • SOCKET | 1 | |
| 164 | 1030-91340 | • DRIVER | 1 | |
| 165 | 848BU36914 | TAPHEAD ASSY | 1 | . |
| 166 | 848BU369M4 | • CASE | 1 | |
| 167 | T3189-15191 | • EYELET | 2 | |
| 168 | T3189-15132 | • COVER | 1 | |
| 169 | T3189-15142 | • CORD HOLDER | 1 | |
| 170 | T3189-15160 | • SPRING | 1 | |
| 171 | 848BU369S0 | • CORD | 1 | |
| 172 | 848JL066A5 | GUARD | 1 | |
| 173 | 848JL06635 | GURD ASSY | 1 | |
| | | | | |
| 175 | 848JL066B2 | • BLADE | 1 | |
| 176 | 4820-72150 | • BOLT TORX T27 | 1 | M4xL16 |
| 177 | 3238-13150 | • NUT | 1 | |
| 178 | T4950-63040 | BOLT TORX T27 | 2 | M6xL30 |
| | | | | |
| 180 | 6242-92110 | GOGGLE | 1 | |
| 181 | 848JG061J1 | COVER | 1 | |

**BC4501WE**

## Fig.2 CUTTER GROUP




# Fig.2 CUTTER GROUP

| Key# | PART NUMBER | DESCRIPTION | Q'ty /UNIT | NOTE |
|---|---|---|---|---|
| 1 | 4050-11110 | HOUSING | 1 | |
| 2 | 4050-11150 | CAP | 1 | |
| 3 | T3042-11210 | JOINT | 1 | |
| 4 | 4050-11250 | ABSORBER-F | 1 | |
| 5 | 4050-11260 | ABSORBER-R | 1 | |
| 6 | 4820-21310 | BOLT T27 | 4 | M5xL30 |
| 7 | T4950-63040 | BOLT T27 | 1 | M6xL30 |
| 8 | 4820-12350 | BOLT T27 | 1 | M5xL10 |
| 9 | 591 42 58-01 | DRUM | 1 | |
| 10 | 06004-06202 | BEARING | 1 | |
| 11 | 04065-03515 | RING | 1 | |
| 12 | 04064-01510 | RING | 1 | |
| 13 | T4950-62040 | BOLT T27 | 4 | M6xL20 |
| 20 | T3042-12100 | PIPE COMP. | 1 | |
| 23 | 6340-12211 | SHAFT | 1 | |
| 28 | 848JJ76100 | GEARCASE ASSY | 1 | |
| 29 | 848JL061A2 | • GEARCASE | 1 | |
| 30 | 06000-06001 | • BEARING | 1 | |
| 31 | 06001-06001 | • BEARING | 1 | |
| 33 | 04065-02812 | • RING | 1 | |
| 34 | 8488AL3500 | • SEAL | 1 | |
| 35 | 848JJ761B0 | • SHAFT | 1 | |
| 36 | 848JL061C3 | • GEAR | 1 | |
| 37 | T4950-60800 | • BOLT TORX | 1 | |
| 38 | T4950-40800 | • BOLT TORX | 1 | |
| 39 | 848JJ761D1 | • PINION | 1 | |
| 40 | 06000-06000 | • BEARING | 1 | |
| 41 | 06004-06202 | • BEARING | 1 | |
| 43 | 04065-03515 | • RING, SNAP | 1 | |
| 44 | 04064-01210 | • RING | 1 | |
| 45 | T4950-63540 | • BOLT TORX | 1 | |
| 46 | 848JL061F4 | • HOLDER (A) | 1 | |
| 47 | 848JL061L0 | • PLATE | 1 | |
| 48 | 848JL061G2 | • HOLDER (B) | 1 | |
| 49 | T3002-13260 | • NUT | 1 | M10xP1.25 |
| 52 | T1501-32120 | • BOLT TORX T27 | 1 | M5xL12 |
| 53 | 848JL066C3 | PLATE | 1 | |
| 70 | 848JL132K1 | BRACKET-UP | 1 | |
| 71 | 848JL132B2 | BRACKET | 1 | |
| 72 | 848JL132C2 | HOLDER | 2 | |
| 73 | 848JL132D1 | HOLDER | 2 | |
| 74 | 848JL132E2 | CUSHION | 6 | |
| 75 | 4820-13180 | BOLT TORX T27 | 4 | M5xL20 |
| 76 | T4950-52540 | BOLT TORX | 2 | |
| 77 | 848JL132L2 | CLAMP | 2 | |
| 80 | 848JL23812 | HANGER ASSY | 1 | |
| | | • HANGER | 1 | |
| | | • CLAMP | 1 | |

| Key# | PART NUMBER | DESCRIPTION | Q'ty /UNIT | NOTE |
|---|---|---|---|---|
| 83 | 4820-13180 | • BOLT TORX T27 | 1 | M5xL20 |
| 90 | 848JJ890R0 | PLATE NAME | 1 | |
| 91 | 8488X10020 | PLATE | 1 | |
| 110 | 848JJ83220 | HANDLE (L) ASSY | 1 | |
| 120 | 848JJ83210 | HANDLE (R) ASSY | 1 | |
| 122 | 8488R40510 | GRIP ASSY | 1 | |
| 123 | 576 04 53-01 | • • HANDLE, HALF SET | 1 | |
| 125 | 848JL033C3 | • • LEVER | 1 | |
| 126 | 848JL033D2 | • • SPRING | 1 | |
| 127 | 848JL033E3 | • • LEVER-S | 1 | |
| 128 | T4506-52110 | • • SWITCH | 1 | |
| 129 | 8488241600 | • • SCREW | 4 | |
| 130 | T4960-53010 | • • SCREW TORX | 1 | |
| 131 | 3320-15310 | • • NUT | 1 | |
| 132 | 8488P00430 | • • CABLE COMP. | 1 | |
| 133 | 8488M10640 | • • CORD COMP., RED | 1 | CB104 |
| 134 | 8488M10450 | • • CORD COMP., BLACK | 1 | CA104 |
| 135 | T3004-14810 | • • TUBE | 1 | |
| 159 | 6220-17202 | HARNESS ASSY | 1 | |
| 161 | 8488U00210 | TOOL SET | 1 | |
| 162 | 09007-00425 | • WRENCH | 1 | |
| 163 | 8488U10050 | • SOCKET | 1 | |
| 164 | 1030-91340 | • DRIVER | 1 | |
| 165 | 848BU36914 | TAPHEAD ASSY | 1 | . |
| 166 | 848BU369M4 | • CASE | 1 | |
| 167 | T3189-15191 | • EYELET | 2 | |
| 168 | T3189-15132 | • COVER | 1 | |
| 169 | T3189-15142 | • CORD HOLDER | 1 | |
| 170 | T3189-15160 | • SPRING | 1 | |
| 171 | 848BU369S0 | • CORD | 1 | |
| 172 | 848JL066A5 | GUARD | 1 | |
| 173 | 848JL06635 | GURD ASSY | 1 | |
| 175 | 848JL066B2 | • BLADE | 1 | |
| 176 | 4820-72150 | • BOLT TORX T27 | 1 | M4xL16 |
| 177 | 3238-13150 | • NUT | 1 | |
| 178 | T4950-63040 | BOLT TORX T27 | 2 | M6xL30 |
| 179 | 6242-92110 | GOGGLE | 1 | |
| 180 | 848JG061J1 | COVER | 1 | |

## Fig.3 ENGINE GROUP



# Fig.3 ENGINE GROUP

| Key# | PART NUMBER | DESCRIPTION | Q'ty /UNIT | NOTE |
|---|---|---|---|---|
| 1 | 4500-12110 | CYLINDER | 1 | |
| 2 | 1850-12130 | BOLT | 4 | M5x20 |
| 3 | 4500-13120 | GASKET, base | 1 | |
| 4 | 4500-21101 | CRANKCASE COMP. | 1 | |
| 5 | 2629-21130 | • PIN | 3 | |
| 6 | 4500-21140 | GASKET, case | 1 | |
| 7 | 06030-06201 | BEARING | 2 | |
| 8 | 4810-21210 | OIL SEAL | 1 | |
| 9 | 1650-21220 | OIL SEAL | 1 | |
| 10 | 01252-30530 | BOLT | 4 | M5x30 |
| 11 | 04065-03212 | SNAP RING | 1 | |
| 12 | 4500-41110 | PISTON | 1 | |
| 13 | 8488C40300 | RING | 2 | |
| 14 | 2850-41310 | PIN | 1 | |
| 15 | 1300-41320 | RING | 2 | |
| 16 | T2100-41410 | BEARING | 1 | |
| 17 | 2850-41510 | WASHER | 2 | |
| 18 | 4500-42000 | CRANKSHAFT COMP. | 1 | |
| 19 | 4500-51111 | SHOE, clutch | 2 | |
| 20 | 4500-51220 | SPRING | 1 | |
| 21 | 1200-51211 | SCREW | 2 | |
| 22 | 1200-51230 | WASHER | 2 | |
| 23 | 1200-51241 | WASHER | 2 | |
| 24 | T1153-71110 | ROTOR | 1 | |
| 25 | T1153-71200 | COIL ASSY | 1 | |
| 26 | 4500-71220 | • CORD | 1 | |
| 27 | 2616-71320 | • CAP | 1 | |
| 28 | T1153-71250 | • PIN | 2 | |
| 29 | 5500-72130 | • GROMMET | 1 | |
| 30 | 5500-72110 | • CAP, plug | 1 | |
| 31 | 5500-72120 | • SPRING | 1 | |
| 32 | T1512-71320 | • TUBE | 1 | |
| 33 | 3350-14150 | BOLT | 2 | |
| 34 | 1650-43230 | NUT | 1 | |
| 35 | 1000-43240 | KEY | 1 | |
| 36 | 4500-15110 | MUFFLER | 1 | |
| 37 | 01252-30565 | BOLT | 2 | M5x65 |
| 38 | 3310-31720 | BOLT | 1 | M5x14 |
| 39 | 4700-15212 | GASKET | 1 | |
| 40 | 4500-15221 | PLATE | 1 | |
| 41 | 0263-90514 | SCREW | 1 | M5x14 |
| 42 | T1117-31111 | COVER | 1 | |
| 43 | 3310-12281 | BOLT | 4 | M5x20 |
| 44 | 4500-31210 | PLATE | 1 | |
| 45 | 4500-32110 | COVER | 1 | |
| 46 | 4500-32120 | SCREW | 4 | M5x12 |
| 47 | 4500-32210 | GUARD | 1 | |
| 48 | 3699-90332 | SPARKPLUG | 1 | BPMR7A |
| 49 | 1852-72121 | GROMMET | 1 | |
| 50 | T1153-71240 | CORD | 1 | |
| 51 | T1006-73230 | CORD, earth | 1 | |
| 52 | 8488K40010 | CLAMP | 1 | |
| 53 | 4500-75100 | RECOIL ASSY | 1 | |
| 54 | 4500-75120 | • REEL | 1 | |
| 55 | 4500-75150 | • SCREW | 1 | |
| 56 | 1850-75130 | • SPRING, spiral | 1 | |
| 57 | 4500-75180 | • COLLAR | 1 | |
| 58 | 4500-75190 | • ARM | 1 | |
| 59 | 4500-75160 | • ROPE | 1 | |
| 60 | 1140-75320 | • KNOB | 1 | |
| 61 | 5500-75170 | • PLATE, stopper | 1 | |

| Key# | PART NUMBER | DESCRIPTION | Q'ty /UNIT | NOTE |
|---|---|---|---|---|
| 62 | 4500-75210 | PULLEY | 1 | |
| 63 | 4500-75511 | SCREW | 4 | M6x14 |
| 64 | 4700-75310 | COLLOR | 1 | |
| 65 | 4500-13162 | INSULATOR | 1 | |
| 66 | 4500-13181 | SCREW | 2 | M5x20 |
| 67 | 848G6014B1 | GASKET, insulator | 1 | |
| 68 | 4500-13130 | GASKET, carburetor | 1 | |
| 69 | 4500-81001 | CARBURETOR ASSY | 1 | |
| 70 | 1850-81450 | • BODY ASSY | 1 | |
| 71 | 3306-81380 | • • SCREEN | 1 | |
| 72 | 3356-81310 | • • VALVE | 1 | |
| 73 | 1850-81270 | • • SPRING | 1 | |
| 74 | 1850-81220 | • • SCREW | 1 | |
| 75 | 3310-81250 | • • PIN | 1 | |
| 76 | 3310-81230 | • • LEVER | 1 | |
| 77 | 1850-81490 | • BODY, purge | 1 | |
| 78 | 1850-81520 | • COVER, pump | 1 | |
| 79 | 1751-81510 | • PUMP, priming | 1 | |
| 80 | 3310-81260 | • DIAPHRAGM | 1 | |
| 81 | 1850-81470 | • GASKET, diaphragm | 1 | |
| 82 | 1065-81420 | • DIAPHRAGM, pump | 1 | |
| 83 | 1065-81410 | • GASKET, pump | 1 | |
| 84 | 5500-81160 | • WASHER | 1 | |
| 85 | 1751-81130 | • RING | 1 | |
| 86 | 1881-81140 | • SWIVEL | 1 | |
| 87 | 4500-81150 | • VALVE ASSY | 1 | |
| 88 | 1752-81110 | • SCREW | 2 | |
| 89 | 5500-81120 | • BRACKET | 1 | |
| 90 | 1751-81180 | • NUT, adjuster | 1 | |
| 91 | 5730-81170 | • SCREW, adjuster | 1 | |
| 92 | 1881-81130 | • RING | 1 | |
| 93 | 1850-81530 | • SCREW | 4 | |
| 94 | 1484-81610 | • NEEDLE | 1 | |
| 95 | 1491-81160 | • SPRING | 1 | |
| 96 | 1881-81190 | • WASHER | 1 | |
| 97 | 1881-81240 | • O-RING | 1 | |
| 98 | 0263-90550 | SCREW | 2 | |
| 99 | T1184-82101 | BODY ASSY | 1 | |
| 100 | T1184-82130 | • PLATE, choke | 1 | |
| 101 | 4500-82140 | • LEVER, choke | 1 | |
| 102 | 2630-33610 | • SCREW | 1 | |
| 103 | 4500-82170 | ELEMENT | 1 | |
| 104 | 4500-82202 | COVER ASSY | 1 | |
| 105 | 5500-82221 | • KNOB | 1 | |
| 106 | T1015-85005 | TANK ASSY | 1 | |
| 107 | T1015-85202 | • CAP ASSY | 1 | |
| 108 | 4500-85300 | • • HOLDER ASSY | 1 | |
| 109 | 5601-85260 | • • FILTER | 1 | |
| 110 | 4500-85220 | • • PACKING | 1 | |
| 111 | 4820-85260 | • • STOPPER | 1 | |
| 112 | T1015-85300 | • PIPE COMP | 1 | |
| 113 | 3302-85400 | • FILTER ASSY | 1 | |
| 114 | 1260-85460 | • CLIP | 1 | |
| 115 | 4500-22110 | GUARD | 1 | |
| 116 | 0263-90514 | SCREW | 1 | M5x4 |
| 117 | T1184-31911 | GUARD | 1 | |
| 118 | 0263-90525 | SCREW | 4 | |
| 119 | 1970-31151 | LABEL, cover | 1 | |
| 120 | T1117-75412 | LABEL, recoil | 1 | |
| 121 | 4500-81910 | COVER | 1 | |