848JL393B0 (602)

ZENOAH
KOMATSU

PARTS LIST

BRUSHCUTTERS

BCZ4500CL
BCZ5000CL

NOTE :

1. Use KOMATSU ZENOAH genuine parts as specified in the parts list for repair and/or replacement.
2. KOMATSU ZENOAH does not warrant the machines, which have been damaged by the use of any parts other than those specified by the company.
3. When placing parts orders for repair and/or replacement, check if the model name and the serial number are applicable to those specified in the parts list, then use parts number described in the parts list.
4. The contents described in the parts list are accurate as of the date and may change due to improvement.
5. The parts for the machine shall be supplied ten (10) years after the machine is discontinued. [It is possible that some specific parts may be subject to change of their delivery term and list price within the limit of ten (10) years after the machine is discontinued. It is also possible that some parts may be available even after the limit of ten (10) years.]

February 2006

APPLICABLE SERIAL NUMBERS:

DRIVE UNIT	51000101 and up
ENGINE UNIT	51000101 and up

Fig.1 CUTTER GROUP




Fig.1 CUTTER GROUP

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
20	848JL05823	PIPE COMP.	1	
23	848JL058E1	SHAFT	1	
24	848JL05832	JOINT COMP.	1	
25	848JL058F0	SLEEVE	1	
29	848JL06100	GEARCASE ASSY	1	
30	06000-06001	• BEARING	1	
31	06001-06001	• BEARING	1	
33	04065-02812	• RING	1	
34	8488AL3500	• SEAL	1	
35	848JL061B4	• SHAFT	1	
36	848JL061C2	• GEAR	1	
37	T4950-60800	• BOLT TORX	1	
38	T4950-40800	• BOLT TORX	1	
39	848JL061D3	• PINION	1	
40	06000-06000	• BEARING	1	
41	06004-06202	• BEARING	1	
43	04065-03515	• RING, SNAP	1	
44	3130-13270	• RING	1	
45	T4950-63540	• BOLT TORX	1	
46	848JL061F3	• HOLDER (A)	1	
47	848JL061L2	• PLATE	1	
48	848JL061G2	• HOLDER (B)	1	
49	848JL061K1	• NUT M12xP1.25	1	
50	848JL061J3	• COVER	1	
51	04065-01110	• SNAP RING	1	
52	T1501-32120	BOLT TORX M5xL12 T27	1	
53	848JL066C2	PLATE	1	
70	848JL031A3	FRAME	1	
71	848JL031E2	BRACKET-F	1	
72	848JL031F3	BRACKET-L	1	
73	8488251601	SCREW TP5(P-tight)xL16 T27	7	
74	848JL031B3	HOLDER	1	
75	848JL031C2	BAND	1	
76	848JL031J3	ABSORBER	2	
77	848JL031N3	SPRING	1	
78	4820-85510	BOLT TORX M5xL16 T27	3	
79	01642-20508	WASHER	3	
80	848JL032L2	CLAMP	2	
81	848JL031K3	ABSORBER	3	
82	848JL031P3	SPRING	2	
83	T4950-62040	BOLT TORX	1	
90	848JL032C2	BRACKET-UP	1	
91	848JL032D2	BRACKET-LO	1	
92	848JL032G2	KNOB	1	
101A	848JJ090R1	PLATE NAME	1	BCZ4500CL
101B	848JL090R1	PLATE NAME	1	BCZ5000CL
102	6425-12552	PLATE	1	
121	848JL03212	HANDLE COMP.	1	
122	848JL03313	GRIP ASSY	1	
123	848JL033A3	• BODY-R	1	
124	848JL033B4	• BODY-L	1	
125	848JL033C3	• LEVER	1	
126	848JL033D2	• SPRING	1	
127	848JL033E3	• LEVER-S	1	
128	T4506-52110	• SWITCH	1	
129	8488241600	• SCREW	4	
130	T4960-53010	• SCREW TORX	1	
131	3320-15310	• NUT	1	
132	8488P00111	• CABLE COMP.	1	
133	8488M10060	• CORD COMP.	2	
134	8488H27501	• TUBE	1	
151	848JL092A2	BLADE	1	
159	848JL03611	HARNESS ASSY	1	
160	848JL036F0	• HIP PAD ASSY	1	
161	848JL092B1	COVER BLADE	1	
162	8488U00001	TOOL SET	1	
163	T4017-91130	• SOCKET	1	
164	3540-91110	• BAR	1	
165	BC00A29	TAPHEAD ASSY	1	ACC.
166	848JL069M2	• CASE	1	
167	T3189-15191	• EYELET	2	
168	848JL069N0	• COVER	1	
169	T3189-15142	• CORD HOLDER	1	
170	T3189-15160	• SPRING	1	
171	T3189-15180	• CORD	1	
172	848JL066A4	GUARD	1	
173	848JL06634	GURD ASSY	1	
175	848JL066B2	• BLADE	1	
176	4820-72150	• BOLT TORX M4xL16 T27	1	
177	3238-13150	• NUT	1	
178	T4950-63040	BOLT TORX	2	

Fig.2 ENGINE GROUP




Fig.2 ENGINE GROUP

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	848GD01211	CYLINDER COMP.	1	
2	848GD012C1	• COVER, TR, S	1	
3	848GD012D1	• COVER, TR, F	1	
4	848H7012E1	• GASKET, TR	2	
5	4820-16310	• BOLT TORX M4xL10 T27	8	
6	848H7012B1	GASKET	1	
7	4820-12130	BOLT TORX M5xL22 T27	4	
8	3699-91867	SPARK PLUG	1	CMR7H
9	848H702111	CRANKCASE COMP.	1	
10	2629-21130	• PIN	3	
11	T1400-21140	GASKET, CASE	1	
12	84889F3511	BEARING	2	
13	T4019-21210	SEAL	1	
14	1400-21220	SEAL	1	
15	04065-03515	RING, SNAP	1	
16	4820-21310	BOLT TORX M5xL30 T27	4	
17	848GD041A2	PISTON	1	
18	2670-41211	RING	2	
19	2880-41310	PIN	1	
20	3350-41320	SNAP RING	2	
21	1400-41410	BEARING	1	
22	2670-41510	WASHER	2	
23	848H704201	CRANKSHAFT COMP.	1	
30	848H7015A1	MUFFLER	1	
31	8488156700	BOLT M5xL65	2	
32	4820-85510	BOLT TORX M5xL16 T27	2	
33	848H7015C1	GASKET	1	
34	848H7015D1	PLATE	1	
40	848H7053A2	COVER	1	
41	4820-85510	BOLT TORX M5xL16 T27	4	
42	848H703110	COVER-TOP ASSY	1	
43	848H7031E0	• TAPE	1	
44	848H7090B1	• LABEL, COVER	1	
45	848H7031N1	COVER-BOTTOM	1	
46	T4970-52000	SCREW TORX 5xL20	2	
47	8488151002	BOLT TORX M5xL10 T27	2	
50	848H705110	SHOE COMP.	1	
51	1200-51211	SCREW	2	
52	1200-51230	WASHER	2	
53	1200-51241	WASHER	2	
60	848H7471A0	ROTOR	1	
61	848H707122	COIL ASSY	1	
63	T4950-42200	BOLT TORX M4xL22 T27	2	
64	1260-71261	SPACER	2	
65	T1400-72110	CAP	1	
66	1900-72120	SPRING	1	
67	T1400-73200	CORD COMP.	1	
68	1400-43230	NUT	1	
69	1000-43240	KEY	1	
70	2850-71320	TUBE	1	
80	848H707511	RECOIL ASSY	1	
82	848H7475C0	• REEL	1	
83	848H7075L1	• PLATE, CAM	1	
84	848H7075K1	• SPRING, DAMPER	1	
85	848H7075B1	• SPRING, SPIRAL	1	
86	848H7075E1	• SCREW	1	
87	848H7075F1	• ROPE	1	
88	848H7075J1	• KNOB	1	
89	848H7075G1	• STOPPER	1	

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
90	848H707521	PULLEY ASSY	1	
92	848H7075R1	• RATCHET	2	
93	848H7075S0	• SPRING	2	
94	1034-72180	• E RING	2	
95	4820-32120	BOLT TORX	4	
100	848H7014A3	INSULATOR	1	
101	848H7082A2	PIPE	1	
102	848H7014B1	GASKET	1	
103	848H7014C1	GASKET, CARB	1	
104	T4950-52021	BOLT TORX M5xL20 T27	3	
105	848H708103	CARBURETOR ASSY	1	
106	848H7082F0	KNOB	1	
107	2850-81900	PUMP	1	
108	8488F40450	TUBE	1	
109	848GG08310	BODY ASSY	1	
110	848GG083D0	• GROMMET	1	
111	848H708321	COVER ASSY	1	
112	8488052011	• SCREW	2	
113	848H7083Y0	• GUARD	1	
114	8488241600	• SCREW	1	
115	848H7083F1	ELEMENT	1	
116	T4012-82510	PLATE	1	
117	4820-15310	BOLT TORX M5xL50 T27	2	
118	4820-85510	BOLT TORX M5xL16 T27	1	
119	848H708220	BRACKET ASSY	1	
120	T1600-13170	• SCREW	1	
121	0282-10604	• NUT	1	
122	8488251601	SCREW M5xL16 T27	1	
123	8488141200	BOLT M4x12 T27	1	
124	848GG082L1	STOPPER	1	
130	848H708502	TANK ASSY	1	
131	T1015-85202	• CAP ASSY	1	
132	4500-85300	• • HOLDER ASSY	1	
133	4500-85220	• • PACKING	1	
134	5601-85260	• • FILTER	1	
135	4820-85260	• • STOPPER	1	
136	848H708531	• PIPE COMP.	1	
137	3302-85400	• FILTER	1	
138	2841-31280	• COLLER	1	
139	8488153000	BOLT	4	
151	848GD090C1	LABEL, RECOIL	1	
175	T4950-62040	BOLT TORX M6xL20 T27	4	
181	848JL05303	HOUSING ASSY	1	
182	848JL053A5	• HOUSING	1	
183	06004-06202	• BEARING	1	
184	04065-03515	• RING, SNAP	1	
185	848JL051A1	• DRUM	1	
186	04064-01510	• SNAP RING	1	
187	4820-12350	• BOLT TORX M5xL10 T27	1	
188	T4950-63040	• BOLT TORX M5xL30 T27	1	
189	848JL053D1	• ABSSORBER	1	
190	848JL053H0	• ABSSORBER	1	
191	04065-04518	• RING	1	
192	848JL053B1	• CLAMP	1	
193	848JL053Y0	• SPACER	1	

Fig.3 ENGINE GROUP





Fig.3 ENGINE GROUP

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	848H701211	CYLINDER COMP.	1	
2	848H7012C1	• COVER, TR, S	1	
3	848H7012D1	• COVER, TR, F	1	
4	848H7012E1	• GASKET, TR	2	
5	4820-16310	• BOLT TORX M4xL10 T27	8	
6	848H7012B1	GASKET	1	
7	4820-12130	BOLT TORX M5xL22 T27	4	
8	3699-91867	SPARK PLUG	1	CMR7H
9	848H702111	CRANKCASE COMP.	1	
10	2629-21130	• PIN	3	
11	T1400-21140	GASKET, CASE	1	
12	84889F3511	BEARING	2	
13	T4019-21210	SEAL	1	
14	1400-21220	SEAL	1	
15	04065-03515	RING, SNAP	1	
16	4820-21310	BOLT TORX M5xL30 T27	4	
17	848H7041A2	PISTON	1	
18	T1400-41210	RING	2	
19	2880-41310	PIN	1	
20	3350-41320	SNAP RING	2	
21	1400-41410	BEARING	1	
22	2670-41510	WASHER	2	
23	848H704201	CRANKSHAFT COMP.	1	
30	848H7015A1	MUFFLER	1	
31	8488156700	BOLT M5xL65	2	
32	4820-85510	BOLT TORX M5xL16 T27	2	
33	848H7015C1	GASKET	1	
34	848H7015D1	PLATE	1	
40	848H7053A2	COVER	1	
41	4820-85510	BOLT TORX M5xL16 T27	4	
42	848H703110	COVER-TOP ASSY	1	
43	848H7031E0	• TAPE	1	
44	848H7090B1	• LABEL, COVER	1	
45	848H7031N1	COVER-BOTTOM	1	
46	T4970-52000	SCREW TORX 5xL20	2	
47	8488151002	BOLT TORX M5xL10 T27	2	
50	848H705110	SHOE COMP.	1	
51	1200-51211	SCREW	2	
52	1200-51230	WASHER	2	
53	1200-51241	WASHER	2	
60	848H7471A0	ROTOR	1	
61	848H707122	COIL ASSY	1	
63	T4950-42200	BOLT TORX M4xL22 T27	2	
64	1260-71261	SPACER	2	
65	T1400-72110	CAP	1	
66	1900-72120	SPRING	1	
67	T1400-73200	CORD COMP.	1	
68	1400-43230	NUT	1	
69	1000-43240	KEY	1	
70	2850-71320	TUBE	1	
80	848H707511	RECOIL ASSY	1	
82	848H7475C0	• REEL	1	
83	848H7075L1	• PLATE, CAM	1	
84	848H7075K1	• SPRING, DAMPER	1	
85	848H7075B1	• SPRING, SPIRAL	1	
86	848H7075E1	• SCREW	1	
87	848H7075F1	• ROPE	1	
88	848H7075J1	• KNOB	1	
89	848H7075G1	• STOPPER	1	

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
90	848H707521	PULLEY ASSY	1	
92	848H7075R1	• RATCHET	2	
93	848H7075S0	• SPRING	2	
94	1034-72180	• E RING	2	
95	4820-32120	BOLT TORX	4	
100	848H7014A3	INSULATOR	1	
101	848H7082A2	PIPE	1	
102	848H7014B1	GASKET	1	
103	848H7014C1	GASKET, CARB	1	
104	T4950-52021	BOLT TORX M5xL20 T27	3	
105	848H708103	CARBURETOR ASSY	1	
106	848H7082F0	KNOB	1	
107	2850-81900	PUMP	1	
108	8488F40450	TUBE	1	
109	848GG08310	BODY ASSY	1	
110	848GG083D0	• GROMMET	1	
111	848H708321	COVER ASSY	1	
112	8488052011	• SCREW	2	
113	848H7083Y0	• GUARD	1	
114	8488241600	• SCREW	1	
115	848H7083F1	ELEMENT	1	
116	T4012-82510	PLATE	1	
117	4820-15310	BOLT TORX M5xL50 T27	2	
118	4820-85510	BOLT TORX M5xL16 T27	1	
119	848H708220	BRACKET ASSY	1	
120	T1600-13170	• SCREW	1	
121	0282-10604	• NUT	1	
122	8488251601	SCREW M5xL16 T27	1	
123	8488141200	BOLT M4x12 T27	1	
124	848GG082L1	STOPPER	1	
130	848H708502	TANK ASSY	1	
131	T1015-85202	• CAP ASSY	1	
132	4500-85300	• • HOLDER ASSY	1	
133	4500-85220	• • PACKING	1	
134	5601-85260	• • FILTER	1	
135	4820-85260	• • STOPPER	1	
136	848H708531	• PIPE COMP.	1	
137	3302-85400	• FILTER	1	
138	2841-31280	• COLLER	1	
139	8488153000	BOLT	4	
151	848H7090C1	LABEL, RECOIL	1	
175	T4950-62040	BOLT TORX M6xL20 T27	4	
181	848JL05303	HOUSING ASSY	1	
182	848JL053A5	• HOUSING	1	
183	06004-06202	• BEARING	1	
184	04065-03515	• RING, SNAP	1	
185	848JL051A1	• DRUM	1	
186	04064-01510	• SNAP RING	1	
187	4820-12350	• BOLT TORX M5xL10 T27	1	
188	T4950-63040	• BOLT TORX M5xL30 T27	1	
189	848JL053D1	• ABSSORBER	1	
190	848JL053H0	• ABSSORBER	1	
191	04065-04518	• RING	1	
192	848JL053B1	• CLAMP	1	
193	848JL053Y0	• SPACER	1	

Fig.4 CARBURETOR



Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	848H708103	CARBURETOR ASSY	1	
2	3306-81380	• SCREEN	1	
3	848H7081H0	• COVER	1	
4	848H7081P0	• SCREW	1	
5	3304-81140	• GASKET	1	
6	1172-81150	• DIAPHRAGM	1	
7	3356-81310	• VALVE	1	
8	2850-81290	• GASKET	1	
9	3310-81260	• DIAPHRAGM	1	
10	848H7081G0	• COVER	1	
11	1488-81370	• SPRING	1	
12	2812-81330	• NEEDLE	1	
13	3415-81490	• CAP	2	
14	3310-81240	• SCREW	1	
15	3310-81250	• PIN	1	
16	3310-81230	• LEVER	1	
17	848H7081T1	• SHAFT	1	
18	1282-81460	• SPRING	1	
19	1145-81540	• SCREW	1	
20	848H7081U1	• VALVE	1	
21	2880-81470	• SCREW	3	
22	1751-81130	• RING	1	
23	1751-81190	• WASHER	1	

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
24	1751-81141	• SWIVEL	1	
25	1148-81390	• RING	1	
26	848H7181Z1	• LEVER, throttle	1	
27	2670-81410	• SPRING	1	
28	3350-81350	• SPRING	1	
29	3350-81220	• BALL	1	
30	848H7181E0	• SHAFT ASSY, choke	1	
31	848H7180C0	• VALVE	1	
32	3350-81391	• SPRING	1	
33	3310-81351	• SCREW	4	
34	848H7181B0	• NEEDLE	1	
35	2810-81530	• SPRING	1	
36	2812-81510	• PISTON	1	
37	2812-81520	• BALL	1	
38	848H708200	• BODY ASSY, air valve	1	
39	848H7082A0	• RING, packing	2	
40	848H7082B0	• LINK ROD	1	

ZENOAH
KOMATSU

KOMATSU ZENOAH CO.

1-9 Minamidai, Kawagoe, Saitama, 350-1192 Japan

PRINTED IN JAPAN

PRINTED ON RECYCLED PAPER
IMPRIMÉ SUR PAPIER RECYCLÉ
GEDRUCKT AUF RECYCLING PAPIER
STAMPATO SU CARTA RICICLATA
IMPRESO EN PAPEL RECICLADO