



发电机机组零部件图册

PARTS CATALOGUE

LC13000



Version number: LC/LT-2016-A

隆鑫通用动力股份有限公司

LONCIN MOTOR CO.,LTD.

零件目录使用说明(Instruction for use of parts catalogue)

本零件目录是根据2015年1月所能得到的最新资料编制而成的。

This parts catalogue was prepared based on the latest information available as of January 2015.

请注意2015年1月以后本零部件目录的修订通知。

See the parts catalogue news for any revision that is made after January 2015.

当订购零件时，一定要明确指出其零件编号。

Always specify the part number when ordering a part.

注意本零件目录所给出的图形可能与实际零件外形有所不同。

Note that the illustrations can differ from the actual parts in shape.

当需要对零部件目录的内容进行更改或增加时，本公司将在适当的时间出版修订版，为保证在任何时候都可以使用到最新版本的零部件目录建议拥有最新的修订版本。如果要检查修订版本是否已经发行，请直接与LONCIN联系。

When modifications or additions to this parts catalogue are made , a revised edition will be issued at an appropriate time,

We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times. To check whether a parts catalogue revision has been issued, please contact your LONCIN distributor.

示例 (Example)

序号	零部件图号	零部件名称	Description	数量
No.	Part No.			Quantity
1	380140013-0005	六角头法兰面螺栓	BOLT, FLANGE M6×16	9
2	120230125-T470	气缸头盖组合	COVER COMP.HEAD	1
3	380950400-T470	管夹	CLIP,TUBE	1
4	380741143-T470	通气管	TUBE, BREATHER	1


“零件数量 (Quantity)”栏中数字表示该方框所述部分的数量。

The number given in the “Quantity.” column indicates the quantity of parts used in the section described in that block.


“-”表示数量为0。

“-”means the number require 0 QTY.


气缸头 (CYLINDER HEAD)




曲轴箱体 (CRANKCASE)




曲轴箱盖 (CRANKCASE COVER)




曲轴_活塞 (CRANKSHAFT_PISTON)




配气系统 (ROCKER,CAMSHAFT)




起动器组件 (STARTER SUBASSEMBLY)




化油器 (CARBURETOR)




调速控制 (CONTROL)




转子部件 (FLYWHEEL)




空滤器 (AIR CLEANER)




消声器 (MUFFLER)




油箱 (FUEL TANK)




电机部件 (ALTERNATOR)




机架 (FRAME)




控制面板部件 (COTROL PANEL ASSY.)




扶手、车轮 (HANDLE、KIT)




蓄电池组件 (BATTERY TRAY)






气缸头 (CYLINDER HEAD)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	380140013-0005	六角头法兰面螺栓	BOLT, FLANGE M6×16	9
2	120230125-T470	气缸头盖组合	COVER COMP.HEAD	1
3	380950400-T470	管夹	CLIP,TUBE	1
4	380741143-T470	通气管	TUBE, BREATHER	1
5	120250047-T470	气缸头盖密封垫	PACKING , HEAD COVER	1
6	662360001-T470	迷宫密封垫	PACKING SEAL,MAZE	1
7	150310017-T470	滤网	STRAINER	1
8	110840030-T470	呼吸槽盖板	BREATHING TANK COVER PLATE	1
9	380140039-0003	六角头法兰面螺栓	BOLT, FLANGE M6×8	4
10	380140563-0001	六角头法兰面螺栓	BOLT, FLANGE M12×80	4
11	120080588-T470	气缸头	HEAD COMP., CYLINDER	1
12	270960014-0001	火花塞 F7RTC	SPARK PLUG	1
13	380180139-T470	双头螺栓	BOLT,STUD,EX. 8×42	2




气缸头 (CYLINDER HEAD)

[illegible]




曲轴箱体（CRANKCASE）

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	110810251-T470	曲轴箱体	CRANKCASE	1
2	110260024-T110	密封螺塞	BOLT, DRAIN PLUG	1
3	380450516-T110	平垫圈	WASHER	1
4	111040006-T595	密封螺塞组合	BOLT, DRAIN PLUG	1
5	380650337-T110	油封	OIL SEAL 35×52×7	1
6	283690004-T270	油位报警器	OIL LEVEL ALARM	1
7	380600123-T370	定位销 10×12	PIN, DOWEL 10×12	2
8	270360100-T470	起动电机部件	STARTER MOTOR	1
9	380140362-0001	六角头法兰面螺栓	BOLT, FLANGE M8×85	2
10	281890007-T595	机油保护器	OIL PROTECTION DEVICE	1
11	380140013-0005	六角头法兰面螺栓	BOLT, FLANGE M6×16	1
12	380570001-0001	开口挡圈	SPLIT WASHER	1
13	171630022-T470	调速臂	SHAFT, GOVERNOR ARM	1




曲轴箱盖 (CRANKCASE COVER)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	380140006-0005	六角头法兰面螺栓	BOLT, FLANGE M8×45	9
2	380650337-T110	油封	OIL SEAL 35×52×7	1
3	110820123-T470	曲轴箱盖	CRANKCASE COVER	1
4	110690074-T470	机油尺组合	OIL FILLER CAP.ASSY	1
5	110690080-T470	机油尺组合(塞)	OIL FILLER CAP.ASSY	1
6	110830061-T470	曲轴箱盖密封垫	PACKING, CASE COVER	1
7	380600123-T370	定位销	PIN, DOWEL 10×12	2
8	150350023-T390	机油精滤器组合	OIL FINE FILTER COMBINATION	1
9	171750028-T470	调速齿轮部件	GOVERNOR ASSY.	1
10	381350016-T116	销夹	PIN, LOCK	1
11	150070045-T470	油泵从动轮	OIL PUMP DRIVEN GEAR	1
12	380070022-0005	六角头螺栓	HEXAGON HEADED BOLT M6×12	3
13	150290028-T470	机油滤网	OIL STRAINER	1




曲轴箱盖 (CRANKCASE COVER)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
14	150040035-T470	油泵盖	OIL PUMP COVER	1
15	150120003-T240	机油泵驱动销	DRIVE PIN;OIL PUMP	1
16	150080043-T470	油泵传动轴	OIL PUMP DRIVE SPINDLE	1
17	150050026-T240	内转子	INTERNAL ROTOR	1
18	150060025-T240	外转子	EXTERNAL ROTOR	1
19	380840925-T470	密封圈	"O" RING	1
20	381150370-T240	压簧	SPRING,FRICTION	1
21	380640016-0001	钢球	FRICTION BALL	1




曲轴_活塞 (CRANKSHAFT_PISTON)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	130070182-T430	活塞环组合	RING SET,PISTON	1
2	130030205-T430	活塞	PISTON	1
3	380560057-T110	钢丝挡圈	CLIP,PISTON PIN	2
4	130060064-T430	活塞销	PIN,PISTON	1
5	130150120-T470	连杆	CONNECTING ROD ASSY	1
6	130290449-T470	曲轴部件	CRANKSHAFT ASSY	1
7	130450031-T470	平衡轴	WEIGHT,BALANCER	1
8	380450895-T430	平垫圈	WASHER	1




配气系统 (ROCKER,CAMSHAFT)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	380140451-0001	六角头法兰面螺栓	BOLT, FLANGE M8×20	4
2	140450064-T470	气门摇臂组合	ROCKER ARM ASSY.	1
3	380600167-T270	定位销	PIN, DOWEL 4×12	2
4	140670035-T116	挺杆组合	PUSH ROD	2
5	140690004-T110	挺柱	LIFTER, VALVE	2
6	140020133-T470	凸轮轴组合	CAMSHAFT ASSY.	1
7	140320002-T110	气门调整帽	ROTATOR, VALVE	2
8	140390015-T11D	气门锁夹	VALVE LOCKER	4
9	140380021-T11D	气门弹簧座	RETAINER, VALVE SPRING	2
10	140340044-T470	气门内弹簧	SPRING, VALVE	2
11	140360010-T110	气门内弹簧座圈	SEAT, VALVE SPRING	2
12	140400012-T110	挡油罩	SEAL, VALVE STEM	1
13	500550075-T470	气门套件	VALVE ASSY.	1




化油器 (CARBURETOR)

[illegible]




调速控制 (CONTROL)

序号 Ser.No.	零部件编号 Part No.	零部件名称	Description	数量 Quantity
1	380140037-0003	六角头法兰面螺栓	BOLT, FLANGE M6×10	4
2	171680115-T470	油门操纵手柄组合	CONTROL ASSY.	1
3	171600090-T470	调速弹簧	SPRING, GOVERNOR A	1
4	171590027-T470	油门拉杆	ROD, GOVERNOR	1
5	171610025-T470	节气门复位弹簧	SPRING, GOVERNOR B	1
6	171620036-T470	调速支架	ARM, GOVERNOR	1
7	380250002-0001	方头平端紧定螺钉	BOLT, GOVERNOR ARM	1
8	380370066-0001	六角法兰面螺母 M6	NUT, FLANGE, M6	1




转子部件 (FLYWHEEL)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	270920319-T470	点火线圈	COIL ASSY., IGNITION	1
2	380140086-0002	六角头法兰面螺栓	BOLT, FLANGE M6×22	2
3	270020268-T470	磁电机转子部件 50HZ	FLYWHEEL COMP.	1
4	380450702-0001	平垫圈	WASHER	1
5	380140457-0001	六角头法兰面螺栓	BOLT, FLANGE M12×35	1
6	160180034-T430	叶轮	FAN COOLING	1
7	193590028-T470	起动盘	PULLEY, STARTER	1
8	380140091-0005	六角头法兰面螺栓	BOLT, FLANGE M8×25	4




空滤器 (AIR CLEANER)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	180020736-T470	空滤器	AIR CLEANER	1
2	180280085-T470	空滤器座	CASE COMP., AIR CLEANER	1
3	380840924-T470	密封圈	SEAL, AIR CLEANER	1
4	180330051-T470	滤芯支撑板体	SEPARATOR, AIR CLEANER	1
5	180100092-T470	空滤器滤芯组合	ELEMENT, AIR CLEANER ASSY.	1
6	180070221-T470	空滤器壳体盖	COVER, AIR CLEANER	1
7	180270008-T470	空滤器罩锁紧螺栓	BOLT,COVER,AIR CLEANER	2
8	380370048-0001	六角法兰面螺母	NUT,FLANGE	2
9	380020121-T520	六角头轴肩螺栓	BOLT,HEXAGONAL M5×14	6




消声器 (MUFFLER)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	180650113-T470	排气口密封垫	GASKET, EXHAUST,CYLINDER	1
2	380340005-0007	六角螺母M8	NUT, M8	4
3	180590282-T595	排气管	PIPE COMP.,EX	1
4	180660082-T595	消声器密封垫	GASKET, EX., PIPE	1
5	180571869-T595	消声器	MUFFLER	1
6	180960155-T595	消声器护罩	COVER,MUFFLER	1
7	380140215-0003	六角法兰面螺栓M6×14	BOLT, FLANGE, M6×14	5
8	380140004-0004	六角法兰面螺栓M8×20	BOLT, FLANGE, M8×20	1
9	380140091-0005	六角法兰面螺栓M8×25	BOLT, FLANGE, M8×25	1
10	180960156-T595	消声器护罩	COVER,MUFFLER	1
11	180980003-T595	消声器护罩胶条	COVER RUBBER,MUFFLER	1
12	180980004-T595	消声器护罩胶条	COVER RUBBER,MUFFLER	1




油箱 (FUEL TANK)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	170870134-T53K	油箱盖	CAP COMP., FUEL FILLER	1
2	170720014-T525	注油口滤网组合	FILTER, FUEL TANK	1
3	281870016-T560	油传感器卡子	LABEL,FUEL METER	1
4	380220009-0004	十字槽沉头螺钉M5×16	SCREW, FLAT, M5×16	2
5	170740022-T595	油标部件	FUEL METER	1
6	170501104-T595	油箱	FUEL TANK	1
7	170980114-T595	油开关部件	FUEL VALVE	1
8	380140004-0004	六角法兰面螺栓M8×20	BOLT, FLANGE, M8×20	4
9	380450524-T520	平垫圈 8.5	WASHER,FLAT	4
10	170710014-T520	油箱减震垫衬管	COLLAR, TANK CUSHION	4
11	170700050-T520	油箱减震胶垫	RUBBER, FUEL CUSHION	4
12	380950188-0001	油管卡圈	CLIP, TUBE	4
13	380750244-0001	油管	TUBE, FUEL	1




电机部件 (ALTERNATOR)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	380140167-0002	六角头法兰面螺栓	BOLT, FLANGE M5×12	5
2	660030004-T595	电机挡块	PLATE, GUARD	1
3	660050007-T595	电机前端盖	REAR HOUSING, FRONT	1
4	380140001-0006	六角头法兰面螺栓	BOLT, FLANGE M6×12	6
5	660040008-T595	电机风罩	COVER, DUCT	1
6	660080407-T595	电机部件	ALTERNATOR	1
7	660120006-T595	碳刷组合	BRUSH	1
8	660140006-T595	电压接线板	TERMINAL, VOLT CHANGE	1
9	380450515-0001	平垫圈	WASHER, FLAT	1
10	660010011-T595	电机后支撑	HOUSING, RR	1
11	380140566-T470	六角头法兰面螺栓	BOLT, FLANGE M8×190	4
12	380070180-T56P	六角头螺栓	BOLT, HEX. M10×285	1
13	660020008-T595	电机后端盖	COVER, GENERATOR END	1




电机部件 (ALTERNATOR)

[illegible]




机架 (FRAME)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	300720410-T595	机架部件	FRAME	1
2	300770034-T595	机架减震座	RUBBER,SHOCK ABSORBER	1
3	380370007-0004	六角法兰面螺母M8	NUT, FLANGE M8	4
4	380370077-T040	六角法兰面螺母M10	NUT, FLANGE, M10	4
5	303070045-T595	机架护板(前)	FRAME BAFFLE	1
6	303480002-T560	机架护板螺栓	BOLT, FRAME	8
7	380330007-0005	盖型螺母M8	NUT, CAP	8
8	303070046-T595	机架护板(后)	FRAME BAFFLE	1
9	303070047-T595	机架护板(左)	FRAME BAFFLE	1
10	380190163-0001	内六角螺钉M6×16	INNER SIX ANGLE SCREW	8
11	303070048-T595	机架护板(右)	FRAME BAFFLE	1
12	380140102-0004	六角法兰面螺栓M6X25	BOLT, FLANGE, M6X25	1
13	380490022-0002	锁紧垫圈	WASHING,LOCK	1




控制面板部件 (COTROL PANEL ASSY.)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	271851764-T595	控制面板部件	COTROL PANEL ASSY.	1
2	271890043-T536	电压插座组合 12V点烟器	SOCKET	1
3	281910009-T520	电压表	VOLT METER	1
4	272890014-T53K	计时器	HOUR METER	1
5	271890001-T560	电源插座组合 16A/250V	SOCKET	2
6	271890014-T560	电源插座组合 32A/250V	SOCKET	2
7	271290059-T590	过流保护器 37A	CIRCUIT BRERKER	1
8	271290149-T595	过流保护器 32A	CIRCUIT BRERKER	2
9	271290055-T590	过流保护器 16A	CIRCUIT BRERKER	2
10	271920001-T566	整流桥 KBPC2510	RECTIFIER BRIGE	1
11	271290033-T520	过流保护器 10A	CIRCUIT BRERKER	1
12	271950026-T595	面板后罩壳	CASE,CONTROL PANEL	1
13	380690018-0001	十字小盘螺钉/平垫组合	SCREW,PAN 5X14,WASHER ASSY.	8




扶手、车轮 (HANDLE、KIT)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
1	320400019-T560	手把管组合	HANDLE	1
2	320180229-T560	手把胶	RUBBER JACKET	1
3	320750015-T560	手把管限位块	HANDLE, HOLDER	1
4	381000195-T560	堵头	PLUG	1
5	380330007-0005	盖型螺母M8	NUT, CAP	3
6	320420021-T560	手把管连接支架	HANDLE, BRACKET	1
7	380140152-0002	六角头法兰面螺栓M8X45	BOLT, FLANGE	1
8	303490001-T560	扶手支架螺栓M8×46	BOLT, HANDLE	2
9	380140040-0005	六角头法兰面螺栓M8X16	BOLT, FLANGE	12
10	300800036-T595	机架减震座支架	BRACKET,SHOCK ABSORBER	2
11	380370007-0004	六角法兰面螺母M8	NUT, FLANGE, M8	10
12	300770035-T595	机架减震座	RUBBER,SHOCK ABSORBER	2
13	380450205-0001	平垫圈 17	WASHER,FLAT	2




扶手、车轮 (HANDLE、KIT)

[illegible]



蓄电池组件 (BATTERY TRAY)

[illegible]



蓄电池组件 (BATTERY TRAY)

序号	零部件编号	零部件名称	Description	数量
Ser.No.	Part No.			Quantity
2	271270035-0001	正极导线	BATTERY WIRE	1
3	271170003-0001	蓄电池压架	DEPRESSER,BATTERY	1
4	380370048-0001	六角法兰面螺母M6	NUT, FLANGE, M6	12
5	271210001-0001	蓄电池压架连接杆	POLE,BATTERY	2
6	271190016-0001	蓄电池托架	BASE,BATTERY TRAY	1
7	271200012-0001	蓄电池护板	PLATE,BATTERY GUARD	1
8	271180009-0001	蓄电池边框架	GUARD,BATTERY	2
9	380140095-0005	六角头法兰面螺栓M6X30	BOLT, FLANGE	8
10	380140001-0006	六角头法兰面螺栓M6X12	BOLT, FLANGE	2



隆鑫通用动力股份有限公司

Loncin motor co., Ltd.

详细地址：重庆市九龙坡区九龙工业园区华龙大道99号

Add: No. 99 Hualong Road, Jiulongpo District, Chongqing, China

Tel: 86 23 8980 5678/86 23 8980 8505

Fax: 86 23 8906 7566

Email: service@loncinengine.com

Website: www.loncinengine.com

PRINTED IN CHINA