



汽油机零部件图册

PART CATALOGUE

LC1P91F

LC1P96F



版本号 **VERSION No.:** 2013-01

隆鑫通用动力股份有限公司

LONCIN MOTOR CO.,LTD.

零件目录使用说明 (Instruction for use of parts catalogue)

本零件目录是根据2013年1月所能得到的最新资料编制而成的。

This parts catalogue was prepared based on the latest information available as of January 2013.

请注意2013年1月以后本零部件目录的修订通知。

See the parts catalogue news for any revision that is made after January 2013.

当订购零件时，一定要明确指出其零件编号。

Always specify the part number when ordering a part.

注意本零件目录所给出的图形可能与实际零件外形有所不同。

Note that the illustrations can differ from the actual parts in shape.

当需要对零部件目录的内容进行更改或增加时，本公司将在适当的时间出版修订版，为保证在任何时候都可以使用到最新版本的零部件目录建议拥有最新的修订版本。如果要检查修订版本是否已经发行，请直接与LONCIN联系。

When modifications or additions to this parts catalogue are made , a revised edition will be issued at an appropriate time, We recommend obtaining such revisions in order to keep your parts catalogue up-to-date at all times. To check whether a parts catalogue revision has been issued, please contact your LONCIN distributor.


示例 (Example)

序号	零部件图号	零部件名称	Description	数量 (Reqd. QTY)	
No.	Part No.			LC1P91F	LC1P96F
8	120150184-T420	气缸头密封垫	GASKET,CYL	1	/


注 (Note) : 表示LC1P91F有1个 [1 means LC1P91FA has 1 QTY]

“/” 表示LC1P96F没有 [“/” means require 0 QTY]


汽缸头(CYLINDER HEAD)




曲轴箱(CRANK CASE)




曲轴箱盖(CRANKCASE COVER)




曲轴/活塞连杆(CRANKSHAFT/PISTON)




配气系统(GAS DISTRIBUTION ADJUSTMENT)




导风部件 (BLOWER HOUSING)




化油器(CARBURETOR)




飞轮/点火线圈 (FLYWHEEL/COIL ASSY.)




调速控制系统 (CONTROL SYSTEM)




空滤器 (AIR CLEANER)




起动电机 (STARTER MOTOR)






气缸头 (CYLINDER HEAD)

序号 No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)	
				LC1P91F	LC1P96F
1	380020070-0001	六角头轴肩螺栓	BOLT,HEXAGONAL	4	4
2	120220053-0001	气缸头盖组合	COVER COMP.,HEAD	1	1
3	120250042-0001	气缸头盖密封垫	PACKING ,HEAD COVER	1	1
4	380140455-0001	六角头法兰面螺栓	BOLT,CYLINDER HEAD M10×70	6	6
5	120080517-0001	气缸头	HEAD COMP.,CYLINDER	1	1
6	270960059-0001	火花塞	PLUG,SPARK F6RTC	1	1
7	380600123-0001	定位销	PIN,DOWEL φ10×12	2	2
8	120150184-0001	气缸头密封垫	GASKET,CYLINDER	1	/
	120150183-0001	气缸头密封垫	GASKET,CYLINDER	/	1
9	380140013-0005	六角头法兰面螺栓	BOLT,FLANGE M6×16	2	2
10	160190067-0001	空气导流罩	SHROUD COMP	1	1
11	380180091-0001	双头螺栓	BOLT,STUD,IN. M6/8×134	2	2
12	180650074-0001	排气口密封垫	GASKET,MUFFLER	1	1
13	380190168-0001	内六角螺钉	BOLT 5/16-18UNC_L=22	2	2




曲轴箱体(CRANK CASE)

序号 No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)	
				LC1P91F	LC1P96F
1	110810199-0001	曲轴箱体	CRANKCASE	1	/
	110810193-0001	曲轴箱体	CRANKCASE	/	1
2	380650337-0001	油封	OIL SEAL,φ35×φ52×7	1	1
3	110690061-0001	机油尺组合	CAP ASSY	1	1
4	110830054-0001	曲轴箱盖密封垫	PACKING,CASE COVER	1	1
5	380940625-0001	线夹	CLAMP	1	1
6	381350004-0001	销夹	PIN,LOCK	1	1
7	380650339-0001	油封	OIL SEAL	1	1
8	380450559-0001	平垫圈	WASHER	1	1
9	171630020-0001	调速臂	SHAFT,GOVERNOR ARM	1	1
10	380140013-0005	六角头法兰面螺栓	BOLT,FLANGE M6×16	4	4
11	174570001-0001	调压阀盖	COVER	1	1
12	174550001-0001	调压阀密封垫	SEAL	1	1
13	381150550-0001	压簧	SPRING	1	1




序号	零部件图号	零部件名称	Description	数量 (Reqd. QTY)
----	-------	-------	-------------	----------------

[illegible]




曲轴箱盖 (CRANKCASE COVER)

序号 No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)	
				LC1P91F	LC1P96F
1	380140339-0001	六角头法兰面螺栓	BOLT,FLANGE M8×50	10	10
2	380140013-0005	六角头法兰面螺栓	BOLT,FLANGE M6×16	5	5
3	150040033-0001	油泵盖	OIL PUMP COVER	1	1
4	380840665-0001	密封圈	SEAL RING,OIL PUMP	1	1
5	150010076-0001	机油泵部件	OIL PUMP	1	1
6	380650337-0001	油封	OIL SEAL,φ35×φ52×7	1	1
7	110820106-0001	曲轴箱盖	CRANKCASE COVER	1	1
8	110260026-0001	密封螺塞	DRAIN BOLT 3/8-18 Nptf	2	2
9	150350037-0001	机油精滤器组合	OIL FILTER ASSY	1	1
10	380190039-0005	内六角螺钉	BOLT	4	4
11	150490013-0001	机油滤清器座	OIL BAFFLE PLATE	1	1
12	150910001-0001	机油滤清器座密封垫	OIL BAFFLE PLATE SEAL	1	1
13	150570003-0001	机油回油块	RUBBER,OIL DEFLECTOR	1	1
14	150290025-0001	机油滤网	OIL STRAINER	1	1




曲轴箱盖 (CRANKCASE COVER)

[illegible]




曲轴/活塞 (CRANKSHAFT/PISTON)

序号 No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)	
				LC1P91F	LC1P96F
1	130070183-0001	活塞环组合	RING SET	1	/
	130070182-0001	活塞环组合	RING SET	/	1
2	380560057-0001	钢丝挡圈	CLIP,PISTON PIN	2	2
3	130030206-0001	活塞	PISTON	1	/
	130030205-0001	活塞	PISTON	/	1
4	130060064-0001	活塞销	PIN,PISTON	1	1
5	130150092-0001	连杆	ROD ASSY.,CONNECTING	1	1
6	130290397-0001	曲轴部件	CRANKSHAFT COMP	1	1
7	130450027-0001	平衡轴	WEIGHT,BALANCER	1	1
8	380450895-0001	平垫圈	WASHER	2	2
9	130450028-0001	平衡轴	WEIGHT,BALANCER	1	1




配气系统(GAS DISTRIBUTION ADJUSTMENT)

序号 No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)	
				LC1P91F	LC1P96F
1	500550064-0001	气门套件	VALVE ASSY.	1	1
2	140360010-0001	气门内弹簧座圈	SEAT, VALVE SPRING	2	2
3	140400012-0001	挡油罩	SEAL, VALVE STEM	2	2
4	140340025-0001	气门内弹簧	SPRING, VALVE	2	2
5	140380021-0001	气门弹簧座	RETAINER, VALVE SPRING	2	2
6	140390015-0001	气门锁夹	VALVE KEEPER	4	4
7	140450065-0001	气门摇臂组合	VALVE ROCKER ASSY	2	2
8	140710012-0001	推杆限位板组合	PLATE, ASSY	1	1
9	140670036-0001	挺杆组合	ROD, PUSH	2	2
10	140690004-0001	挺柱	LIFTER VALVE	2	2
11	140020101-0001	凸轮轴组合	CAMSHAFT ASSY.	1	1




导风部件 (BLOWER HOUSING)

[illegible]




化油器 (CARBURETOR)

序号 No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)	
				LC1P91F	LC1P96F
1	170430154-0001	化油器密封垫	PACKING,INSULATOR	1	1
2	170440081-0001	化油器隔热垫	INSULATOR,CARBURETOR	1	1
3	170430153-0001	化油器密封垫	PACKING.,CARBURETOR	2	2
4	160190066-0001	空气导流罩	SHROUD COMP	1	1
5	380140013-0005	六角头法兰面螺栓	BOLT,FLANGE M6×16	3	3
6	170021453-0001	化油器	CARBURETOR	1	/
	170021455-0001	化油器	CARBURETOR	/	1
7	380140067-0003	六角头法兰面螺栓	BOLT,FLANGE M6×12	2	2
8	170470008-0001	汽油泵支架	STENT FUEL PUMP	1	1
9	170460010-0001	汽油泵	FUEL PUMP	1	1
10	380960120-0004	卡箍组合	LOOP TUBE	4	4
11	380750401-0001	油管	OIL PIPELINE	1	1
12	380750435-0001	油管	OIL PIPELINE	1	1
13	170010018-0001	燃油滤清器	STRAINER,FUEL	1	1




序号	零部件图号	零部件名称	Description	数量 (Reqd. QTY)
----	-------	-------	-------------	----------------

[illegible]




飞轮/点火线圈 (FLYWHEEL/COIL ASSY.)

序号 No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)	
				LC1P91F	LC1P96F
1	380140457-0001	六角头法兰面螺栓	BOLT,FLANGE M12×35	1	1
2	380450702-0001	平垫圈	WASHER	1	1
3	270020222-0001	磁电机转子部件	FLYWHEEL COMP	1	1
4	380190039-0005	内六角螺钉	BOLT M6×25	4	4
5	270190020-0001	充电线圈部件	COIL ASSY,CHARGE	1	1
6	160200050-0001	发动机导流罩	SHROUD COMP	1	1
7	380140013-0005	六角头法兰面螺栓	BOLT,FLANGE M6×16	4	4
8	270920282-0001	点火线圈	COIL ASSY.,IGNITION	1	1
9	271280038-0001	连接线	OUTPUT WIRE,RECTIFIER	1	1
10	273600005-0001	波纹管	CASING	1	1
11	380190008-0005	内六角螺钉	BOLT M6×20	2	2
12	270880157-0001	调压整流器	RECTIFIER	1	1
13	181600035-0001	隔热垫	INSULATION MAT	1	1
14	380140086-0002	六角头法兰面螺栓	BOLT,FLANGE M6×22	2	2



调速控制系统 (CONTROL SYSTEM)

序号 No.	零部件图号 Part No.	零部件名称	Description	数量 (Reqd. QTY)	
				LC1P91F	LC1P96F
1	380140013-0005	六角头法兰面螺栓	BOLT,FLANGE M6×16	3	3
2	380180153-0001	双头螺栓	BOLT,STUD	1	1
3	171680091-0001	油门操纵手柄组合	CONTORL ASSY	1	1
4	171620031-0001	调速支架	ARM,GOVERNOR	1	1
5	171600055-0001	调速弹簧	SPRING,GOVERNOR	1	1
6	380250002-0001	方头平端紧定螺钉	BOLT,GOVERNOR ARM	1	1
7	380370066-0001	六角法兰面螺母	NUT,FLANGE	1	1
8	171590022-0001	油门拉杆	ROD,GOVERNOR	1	1
9	171650020-0001	阻风门拉杆	ROD,THROTTLE	1	1

[illegible]



隆鑫通用动力股份有限公司

Loncin motor co., Ltd.

详细地址：重庆市九龙坡区九龙工业园区华龙大道99号

Add: No. 99 Hualong Road, Jiulongpo District, Chongqing, China

Tel: 86 23 8980 5678/86 23 8980 8505

Fax: 86 23 8906 7566

Email: service@loncinengine.com

Website: www.loncinengine.com

PRINTED IN CHINA