

931 Chainsaw



Documents

Starter assy

Engine

Clutch

Air filter and carburetor

Handle

Carburetor WT-477A

Tank




Illustration Starter assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
3		093500397R	Starter handle				
4		4098073R	Starter rope				
7		004000132R	Spring				
8		094000033AR	Starter pulley				
13		004000436R	Pin				
14		004000140R	Pawl				
18		3916009R	Washer				
22		50030112	Spring				
26		50030151R	Switch				
27		50030151R	Switch				
28		50030143R	Flywheel				
29		50030151R	Switch				
30		3833080R	Washer				
31		004000142R	Nut				
32		50030272	Screw				
33		50030161	Flange				
34		094600041AR	Screw				
35		094500034R	Washer				
36		094600097AR	Spark plug cap				
37		50030267R	Spring				
38		50030297R	Spark plug				
39		50032025AR	Starter case				
40		50030145	Spacer				
41		50030269R	Screw				
42		50032025AR	Starter case				
43		50030295	Screw				
44		50030142R	Ignition coil				
45		50030160R	Bushing				
46		50030150R	Sheath				




Illustration Engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
25		50030285	Screw				
26		50030003R	Crankcase				
27		50030004R	Screw				
28		50030013R	Seal ring				
29		50030014R	Ring				
30		50030012R	Bearing				
31		50030011R	Crankshaft				
32		61070074	Seal ring				
33		50030010R	Spacer				
34		50030009R	Bearing				
35		50032010	Piston assy Ø37				
36		50032010	Piston assy Ø37				
37		50030006R	Piston ring				
38		50030002R	Cylinder				
39		50030388R	Gasket				
40		50030309	Muffler				
41		50030297R	Spark plug				
42		50032010	Piston assy Ø37				
43		50032008	Gasket set				




Illustration Clutch

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
27		50030138R	Clutch driver				
28		50030372R	Roller cage				
29		50032009	Clutch drum				
30		50030092	Washer				
31		50030350R	Spring				
32		50030090A	Clutch				
33		50032023AR	Chain cover				
34		50030242	Guard				
35		50030100	Spring				
36		3914003R	Nut				
37		3916005R	Washer				
38		50030105	Spacer				
39		50030292	Screw				
40		50030110	Spring				
41		50030106	Bushing				
42		50030107A	Weight				
43		50030122	Cover				
44		50030272	Screw				
45		50030116R	Plug				
46		50030118	Lever				
47		50030111	Spring				
48		50030117	Plug				
49		50030119R	Brake band				
50		50030113	Brake lever				
51		50010148R	Nut				
52		50030121	Spring				




Illustration Air filter and carburetor

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
10		004000025R	Gasket				
13		50030023R	Gasket				
14		50030056R	Gasket				
15		50030177R	Grommet				
16		50030176R	Starter lever				
17		2318610R	Carburetor WT-477A				
18		50030167R	Starter lever				
19		50030284	Spacer				
20		50030022R	Valve				
25		50030276R	Screw				
26		50030308	Knob				
27		50030184R	Ring				
28		50030306R	Cover				
29		50030277R	Air filter				
30		50030281R	Filter				
31		50032008	Gasket set				





Illustration Handle

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
12		50030269R	Screw				
13		50030279	Screw				
14		50032037	Handle kit				
15		50030082A	Throttle lever				
16		50030077	Spring				
17		50030076R	Plug				
18		50030078R	Button				
19		50032037	Handle kit				
20		50030081	Plug				
21		50032012	Thrott.lever/ro				
22		50030080	Spring				
23		50030065R	Handle				
24		50030270	Screw				
25		50030068R	Strap				
26		50030067R	Support				
27		50030271	Screw				

per } mod. 931
for }



16 ■ KIT RIPARAZIONE
REPAIR KIT

22 ● KIT MEMBRANE & GUARNIZIONI
DIAPHRAGM & GASKET SET

Illustration Carburetor WT-477A

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1		2318616	Spring				
2		2318617	Screw				
3		375100078	Shutter				
4		003300209	Screw				
5		2318615	Spring				
6		2318611	Shaft				
7		035000165	Spring				
8		2318618	Screw L				
9		2318619	Screw H				
10		093500115	Spring				
11		035000162	Screw				
12		2318191	Cover				
13		003300202	Screw				
14		003300201	Spindle				
15		2318613	Jet				
16		-	Not available for this product				
17		2318614	Lever				
18		095000164	Ring				
19		003300036	Fittings				
20		2318612	Cover				
21		003300197	Screw				
22		-	Not available for this product				
23		2318610R	Carburetor WT-477A				




Illustration Tank

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1		50030040R	Breather valve				
2		50030390	Bush				
3		50030286	Fittings				
4		50030037R	Band				
5		50032057R	Oil suction				
6		50030329R	Fittings				
7		50030036R	Fuel filter				
8		50032011	Chain tensioner screw				
9		50030125	Plate				
10		50030400	Cover				
11		50030270	Screw				
12		50030127R	Guard				
13		50030052	Clamp				
14		50030024AR	Crankcase				
15		50030269R	Screw				
16		50030140R	Cover				
17		50030139R	Gasket				
18		50030291	Screw				
19		50032020R	Oil pump				
20		50030136R	Worm gear				
21		50032057R	Oil suction				
22		50032057R	Oil suction				
23		50032057R	Oil suction				
24		50030173	Grommet				
25		50032057R	Oil suction				
26		50030272	Screw				
27		50030229R	Support				
28		50030053R	Breather valve				
29		50030085R	Support				
30		50030178AR	Cap				
31		50030175	Screw guide				
32		50030174	Screw guide				
33		50030033	Breather valve				
34		50030374R	Screw				
35		50030268A	Gasket				
36		50030304AR	Cap				
37		50032012	Thrott.lever/ro				
38		50030057	Cover				