

947 Chainsaw



Documents

Engine

Starter assy

Clutch and brake

Tank and air filter

Handle

Carburetor HDA-205

Carburetor HDA-314




Illustration Engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	3	3914003R	Nut				
2	1	50072025A	Muffler				
3	1	50070031R	Gasket				
4	2	50070032R	Seal flange				
5	2	3960073R	Screw				
6	2	3918010R	Washer				
7	4	3860095R	Screw				
8	1	3055115R	Spark plug bpmr7a				
9	2	50070071	Cover				
10	2	50070186	Gasket				
11	8	3960074R	Screw				
12	1	50070207R	Decompressor				
13	2	50070128R	Piston ring Ø42				
14	1	50070117R	Piston pin				
15	1	004900061R	Ring				
16	1	50072032A	Piston assy				
17	1	50070047CR	Gasket				
18	1	097000059A	Spring				
19	1	50070010AR	Manifold				
20	1	50070152	Tube	SN 0463108262			BT4-155-05/13
21	1	50070224B	Carburetor kit HDA-205E				
22	1	50072024B	Cylinder				
23	1	50080133R	Tube				
24	1	50072026	Labels kit				
25	1	026400089BR	Tube				
26	2	007201313R	Seal ring				
27	4	3860096R	Screw				
28	2	094600042	Plug				
29	1	005000016R	Bearing				
30	1	50070039CR	Gasket				
31	1	50070272AR	Crankshaft				
32	1	094000005R	Bearing				
33	1	3034012R	Bearing				
34	1	50072028A	Gasket set				
35	1	50070180R	Plate				
36	1	50080098R	Crankcase assy				
37	1	50070070	Cover				




Illustration Starter assy

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50070077R	Cable				
2	2	094000097	Screw				
3	2	006000315R	Washer				
4	2	3916004R	Washer				
5	1	094600097AR	Spark plug cap				
6	1	094600169AR	Spring				
7	2	50070148A	Spacer				
8	1	2501001R	Ignition coil				
9	1	097000064AR	Starter handle				
10	1	50070123R	Starter rope				
11	4	3960092AR	Screw				
12	1	50050073R	Spring				
13	1	50070050AR	Starter pulley				
14	1	094500034R	Washer				
15	1	094600041AR	Screw				
16	1	50072005BR	Starter assy		SN 0465187683		
16	1	50072059BR	Starter assy	SN 0465187684			
17	2	004000142R	Nut				
18	2	3833080R	Washer				
19	2	3916009R	Washer				
20	1	50072029	Pawl				
21	1	50260015R	Flywheel				




Illustration Clutch and brake

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50070095AR	Guard				
2	1	095000219AR	Spring				
3	1	097000107	Plug				
4	1	50010088AR	Spring				
5	1	3960045	Screw				
6	1	50070124AR	Plate				
7	1	3026003R	Ring				
8	1	097000146	Lever				
9	1	094500297R	Clutch				
10	1	3993070R	Screw				
11	1	50050125R	Plate				
12	1	50050039R	Brake band				
13	1	006000300	Bushing				
14	1	50070149R	Guard				
15	1	50070033	Spike				
16	2	3960098R	Screw				
17	1	50010148R	Nut				
18	1	3960093	Screw				
19	1	50070081R	Cover				
20	1	094500029AR	Spring				
21	1	50070088	Washer				
22	1	3049007	O-ring				
23	1	50070080	Chain tensioner screw				
24	1	50070087AR	Adjuster nut				
25	1	50072027A	Chain tensioner kit				
26	1	50072060CR	Chain cover assy				
27	1	50070069	Washer				
28	1	50070025R	Worm gear				
29	1	005000165R	Bearing				
30	1	094500761A	Chain sprocket .325				
31	1	375100012AR	Washer				
32	1	097000106R	Plug				
33	1	094600275R	Bar 16" - 41 cm				
33	1	094600285R	Bar 18" - 46 cm				
34	1	001000710R	Chain .325" x .058" (1,5mm)				
34	1	30629007A	Chain .325" x .058" (1,5mm) - 72 links				
35	1	50070084DR	Chain cover				




Illustration Tank and air filter

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50070034R	Knob				
2	1	50072030B	Air filter cover		SN 0465187683		
2	1	50072058B	Air filter cover	SN 0465187684			
3	1	50070036R	Air filter standard				BT1-019-07/07
3	1	50070244R	Air filter optional				BT1-019-07/07
4	1	50070056	Gasket				
5	1	50070066	Deflector				
6	3	3960092AR	Screw				
7	1	50070192	Cover		SN 0465187683		
7	1	50070281DR	Cover	SN 0465187684			
8	1	50052005R	Tank cap				
9	1	3049025	O-ring				
10	1	005000347AR	Grommet				
11	1	50070067A	Tie rod				
12	1	097000229R	Breather valve				
13	1	50070052AR	Screw				
14	1	50070211	Plate				
15	1	50072010BR	Oil filter				
16	1	094600369R	Guard				
17	1	094600041AR	Screw				
18	5	50050067R	Spacer				
19	1	50080068R	Air filter support	SN 0463108262			BT4-155-05/13
20	1	2317021R	Switch				
21	1	2317013R	Guard				
22	1	50070062	Spike				
23	2	3960098R	Screw				
24	1	50070055R	Plate				
25	1	50070054R	Tube				
26	1	50170051BR	Oil pump				BT4-126-10/07
27	2	3960074R	Screw				
28	1	3960091AR	Screw				
29	1	50070228R	Lever				
30	5	3860099R	Screw				
31	1	50070007GR	Crankcase				





Illustration Handle

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50072009R	Cap				
2	1	099900090R	Ring				
3	3	50070049R	Support				
4	1	3960073R	Screw				
5	3	50070024R	Spring				
6	3	3057005R	Washer				
7	2	50010061R	AV-mount				
8	1	50070182	Strap				
9	1	50060039	Tube				
10	1	50080134R	Tube				
11	1	2318817R	Air purge				
12	1	50070259	Throttle kit				BT4-142-05/10
13	1	50050214AR	Cover				
14	1	50050046AR	Lever				
15	1	097000028R	Spring				
16	1	50070065BR	Tank assy				
17	3	3960099R	Screw				
18	1	094500577AR	Breather valve				
19	1	094500575R	Spring				
20	1	50050071R	Breather valve				
21	1	50010218R	Fuel filter				
22	1	50070064	Fuel line				
23	4	094600041AR	Screw				
24	1	3960091AR	Screw				
25	1	50070181	Strap				
26	1	3916005R	Washer				
27	1	4098377R	Band				

FINO A NOVEMBRE 2004
TILL NOVEMBER 2004
BIS NOVEMBER 2004
HASTA NOVIEMBRE 2004
JUSQU'A NOVEMBRE 2004



DA NOVEMBRE 2004
FROM NOVEMBER 2004
AB NOVEMBER 2004
DESDE NOVIEMBRE 2004
DEPUIS NOVEMBRE 2004

89 KIT RIPARAZIONE
REPAIR KIT







Illustration Carburetor HDA-205

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50070155	Shaft				
2	1	50070232	Shaft				
3	1	003300201	Spindle				
4	1	50070154	Cover				
5	1	50070153	Cover				
6	1	50070156	Shutter				
7	1	2318809	Shutter				
8	1	50070160	Throttle lever				
9	2	095000147	Spring				
10	1	380000338	Screw				
11	1	094600148	Spring				
12	1	50070166	Spring				
13	1	50010109	Screw				
14	1	50070163	Screw				
15	2	50010141	Screw				
16	1	50070173	Screw H				
17	1	50070172	Screw L				
18	4	035000162	Screw				
19	1	003300202	Screw				
20	1	50070158	Starter lever				
21	1	50070171	Lever				
22	1	-	Not available for this product				
23	1	50070165	Spring				
24	1	003300204	Fuel filter				
25	1	50070169	Bushing				
27	1	50070232	Shaft				
28	1	2318673	Repair kit				
29	1	50070188	Screw guide				
45	1	50070234	Screw H				
46	1	50070233	Screw L				
51	1	-	Not available for this product				
58	1	2318695	Cap				
59	1	2318694	Cap				
60	1	50070086	Screw guide		SN 0465248122		
62	1	093500574	Screw				
63	1	2318919	Cover				
64	1	2318388	Screw				
65	1	2318913	Shutter				
66	1	2318914	Shaft				
67	1	2318924	Spring				
68	1	093500560	Clamp				
69	1	2318918	Lever				
70	1	004900196	Screw				

Illustration Carburetor HDA-205

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
71	1	2318928	Screw				
72	1	2318934	Cover				
73	4	2318522	Screw				
74	1	2318909	Lever				
75	1	2318535	Ring				
76	1	2318932	Spring				
77	1	2318936	Shaft				
78	1	2318917	Shutter				
79	1	2318916	Screw				
80	1	2318908	Screw				
81	1	2318903	Cap				
82	1	2318889	Cap				
83	1	2318904	Guard				
84	4	2318888	Washer				
85	2	2318532	Spring				
86	1	2318912	Screw L				
87	1	2318911	Screw H				
89	1	2318868	Repair kit				
90	1	50070224B	Carburetor kit HDA-205E				
91	1	2318809	Shutter				
92	1	2318883	Screw				
93	1	50070224B	Carburetor kit HDA-205E				



5 KIT RIPARAZIONE REPAIR KIT

Illustration Carburetor HDA-314

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	2318106	Cap				
2	1	2318109	Adjust. screw MAX				
3	1	2318984	Adjust. screw MIN				
4	2	2318107	Spring				
5	1	2318673	Repair kit				
6	1	2318981AR	Carburetor HDA-314	SN 0465248123			
7	1	50080082R	Screw guide	SN 0465248123			
8	1	50070224B	Carburetor kit HDA-205E				