

981 Chainsaw



Documents

Starter assy and engine

Crankcase, brake and clutch

Fuel tank, air filter and handle

Carburetor





Illustration Starter assy and engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	3	097000092AR	Screw				
2	1	50200015AR	Band				
3	1	098000010R	Manifold				
4	1	094500007R	Piston pin				
5	2	007201198R	Ring				
6	1	006000010	Bearing				
7	1	098000001R	Crankshaft				
8	1	098000312B	Piston assy Ø52				
9	2	3033074	Washer				
10	1	52010441A	Muffler				
11	4	005100906AR	Screw				
12	1	097000215A	Gasket set				
13	2	099900006R	Bearing				
14	1	094500004R	Seal ring				
15	1	094500028R	Key				
16	1	52010458AR	Gasket				
17	1	3055114R	Spark plug				
18	1	097000094CR	Gasket				
19	1	099900014R	Seal ring				
20	2	3801045R	Screw				
21	1	50010215R	Decompressor				
22	1	097000342A	Cover				
23	3	3801052R	Screw				
24	2	098000004R	Piston ring Ø52				
25	1	50102012F	Complete cylinder				
26	1	097000064AR	Starter handle				
27	1	098000079R	Starter rope				
28	1	3918006R	Washer				
30	1	3908036R	Screw				
31	1	097000019C	Flange				
32	1	098000060AR	Spring				
33	2	3916004R	Washer				
34	4	097000092AR	Screw				
35	1	3833080R	Washer				
36	1	3916009R	Washer				
37	1	52010439CR	Pulley				BT4-119-10/06
38	2	094000227	Screw				
39	2	006000315R	Washer				
40	1	094600097AR	Spark plug cap				
41	1	094600169AR	Spring				
42	1	098000067BR	Starter assy				
43	1	097000121AR	Cable				
44	1	098000091AR	Ignition coil				
45	1	52010136BR	Flywheel				

Illustration Starter assy and engine

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
46	1	52012027	Pawl kit				
47	1	2317021R	Switch				
48	1	004000142R	Nut				
49	1	098000121	Labels kit				
50	1	52010093	Screw				
51	1	3078012	Washer				
52	4	3833076R	Washer				
53	2	3960017AR	Screw				
54	1	2317013R	Guard				




Illustration Crankcase, brake and clutch

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	097000135R	Cap				
2	1	099900090R	Ring				
3	1	099900110	Grommet				
5	1	006000102R	Cotter pin				
6	1	097000049A	Starter lever				
7	8	3833073R	Washer				
8	1	093800060B	Screw				
9	1	097000147AR	Oil suction				
10	1	097000078	Cap				
11	2	097000080BR	Stud				
12	1	097000215A	Gasket set				
13	1	098000076	Clamp				
14	1	099900368B	Chain tensioner screw kit				
15	1	61052009BR	Screw				
16	1	097000109A	Spike				
18	2	50010148R	Nut				
19	1	006000251R	Screw				
20	1	50250226R	Clamp				
21	4	3801035	Screw				
22	1	097000524	Crankcase				
23	1	097000069B	Piston pump				
24	1	097000072	Worm gear				
25	1	097000131BR	Oil pump				
26	3	006000024R	Screw				
27	3	006000315R	Washer				
28	1	097000062	Plug				
29	1	097000067	Screw				
30	1	097000068	Clamp				
31	1	097000071A	Spring				
32	2	097000070	Washer				
33	1	097000073R	Washer				
34	1	097000359	Tube				
35	1	006000300	Bushing				
36	1	3023008R	Plug				
37	1	097000229R	Breather valve				
38	1	097000057R	Grommet				
39	2	099900006R	Bearing				
40	1	097000276	Guard				
41	2	50070149R	Guard				
42	1	097000277	Plate				
43	1	50202003CR	Chain cover assy				
44	1	3026003R	Ring				
45	1	097000146	Lever				
46	1	099900152AR	Spring				

Illustration Crankcase, brake and clutch

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
47	1	097000107	Plug				
48	1	50010088AR	Spring				
49	1	097000102	Guard				
50	1	097000106R	Plug				
51	1	50202003CR	Chain cover assy				
52	1	097000275	Plate				
53	1	3960045	Screw				
54	1	50070149R	Guard				
55	1	50010084	Plate				
56	1	097000105	Brake band				
57	1	097000114	Deflector				
58	1	097000098R	Spring				
59	1	097000097R	Washer				
60	1	097000132R	Clutch				
61	1	097000207	Clutch drum				
62	1	097000011R	Bearing				
63	1	006100730R	Ring				
64	1	50010243R	Pin				





Illustration Fuel tank, air filter and handle

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	093000468AR	Screw				
2	1	098000034	Filter cover				
3	1	50010367R	Air filter				BT1-019-07/07
4	1	098000092R	Air filter nylon				BT1-019-07/07
5	1	099900296R	Screw				
6	1	098000183R	Cylinder cover				
7	1	2317021R	Switch				
8	2	61052009BR	Screw				
9	1	098000319AR	Tube				
10	3	3960115R	Screw				
11	1	097000333R	Flange				
12	1	097000025AR	Lever				
13	1	2318760BR	Carburetor WJ-72B				
14	1	097000323A	Screw guide				
15	1	097000280	Support				
16	3	097000092AR	Screw				
17	1	098000043	Fittings				
18	1	3833073R	Washer				
19	1	50200045BR	Complete tank				
20	1	097000024	Cover				
21	1	3960040R	Screw				
22	1	50010157	Throttle lever				
23	1	097000135R	Cap				
24	1	52012044	Rod				
25	4	097000038AR	AV-mount				
26	1	099900083BR	Breather valve				
27	4	006000251R	Screw				
28	1	097000028R	Spring				
29	4	097000061AR	Screw				
30	1	50200017R	Handle				
31	1	50010218R	Fuel filter				
32	1	097000056R	Gasket				
33	1	099900090R	Ring				
35	1	094600126	Tube				
38	1	099900268A	Clamp				
39	1	50200030R	Guard				
40	1	094600041AR	Screw				



- 25 Kit riparazione / Repair kit

Illustration Carburetor

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	028400110	Shutter				
2	1	097000162	Screw				
3	1	097000162	Screw				
4	1	097000161	Spring				
5	1	097000154	Shaft				
6	1	097000155	Shaft				
7	1	2318763	Spring				
8	1	2318772	Screw L				
9	1	2318773	Screw H				
10	1	097000223	Spring				
11	2	097000224	Bushing				
12	5	035000162	Screw				
13	1	097000156	Cover				
14	1	097000323A	Screw guide				
15	1	035000169	Spindle				
16	1	035000164	Spring				
17	1	006000325	Ball				
18	1	50010141	Screw				
19	1	035000151	Shutter				
20	1	035000149	Plate				
21	1	097000160	Lever				
22	1	003300036	Fittings				
23	1	097000157	Cover				
24	4	035000161	Screw				
25	1	2318672	Repair kit				
26	1	2318695	Cap				
27	1	2318694	Cap				