


PB-2520

Published:07/20/2018

TABLE OF CONTENTS

CYLINDER, PISTON, CRANKSHAFT.....	1
CRANKCASE	3
MAGNETO.....	5
AIR CLEANER, CARBURETOR.....	7
CARBURETOR.....	9
FUEL TANK.....	11
MUFFLER	13
RECOIL STARTER, PULLY	15
FAN CASE	17
THROTTLE	19
PIPE.....	21
ACCESSORIES	23


CYLINDER, PISTON, CRANKSHAFT



CYLINDER, PISTON, CRANKSHAFT

KEY NO	LV(+)	Part No	Description	Qty	Standard	Comment
1		A011-001510	CRANKSHAFT,ASY	1		
2	+	V554-000030	BEARING,NEEDLE 9	1	HK0910MPX1V2	
3		A130-002340	CYLINDER	1		
4		V100-000860	GASKET,CYL	1	T0.5	
5		V805-000210	BOLT, TORX 5	4	TB-5*20 12.9	
6		P100-003800	PISTON KIT	1		
7	+	A101-000720	RING, PISTON	1	34*1.5*1.5	
8	+	100013-35430	PIN, PISTON	1	6*9*27.8	
9	+	100015-03931	CIRCLIP, PISTON PIN	2		
10	+	V306-000520	WASHER,CIRCULAR 8	2	9.2*14*T0.8	


CRANKCASE



CRANKCASE

KEY NO	LV(+)	Part No	Description	Qty	Standard	Comment
1		P100-003810	CRANK CASE SET	1		
2	+	900800-36001	BEARING, BALL 6001	1	6001/C3	
3	+	100212-42031	OILSEAL	1	ISCD 12*22*4.5	
4	+	900810-36000	BEARING, BALL	1	6000	
5	+	100212-61830	OILSEAL	1	ISCD 10*20*5	
6	+	V102-000300	GASKET,CRANKCASE	1		
7	+	V805-000220	BOLT, TORX 5	3	TB-5*25 12.9	


MAGNETO



MAGNETO

KEY NO	LV(+)	Part No	Description	Qty	Standard	Comment
1		A409-001320	ROTOR, MAGNETO	1		
2		A411-001750	COIL, IGNITION	1	ID#A10083	
3		100142-12330	KEY, WOODRUFF	1		
4		900515-00008	NUT, FLANGE 8	1	8	
5		V323-000070	WASHER,CIRCULAR 5	2	5.2*10*3	
6		V805-000210	BOLT, TORX 5	2	TB-5*20 12.9	
7		A425-000000	SPARKPLUG	1	BPMR8Y	
8		A427-000013	CAP,SPARK PLUG	1		
9		A426-000010	TERMINAL,SPARKPLUG	1		


AIR CLEANER, CARBURETOR



AIR CLEANER, CARBURETOR

KEY NO	LV(+)	Part No	Description	Qty	Standard	Comment
1		V103-001950	GASKET,INTAKE	1	AF74 T0.5	
2		A200-001130	INSULATOR, INTAKE	1		
3		V805-000210	BOLT, TORX 5	2	TB-5*20 12.9	
4		V103-001960	GASKET,INTAKE	1	AF5400 T0.5	
5		A021-004700	CARBURETOR, DIAPHRAGM	1	ZAMA RE110147A	
6		A259-000010	CAP,LIMITER	1		
7		P100-003820	CASE,CLEANER	1		
8		A244-000330	PLATE, PREVENT	1		
9		V805-000100	BOLT, TORX 5	2	TB-5*65 10.9	
10		A226-002160	ELEMENT, AIR FILTER	1	ID 2520	
11		A232-001920	LID,CLEANER	1		

CARBURETOR




CARBURETOR

KEY NO	LV(+)	Part No	Description	Qty	Standard	Comment
1		A021-004700	CARBURETOR, DIAPHRAGM	1	ZAMA RE110147A	
2	+	P005-000010	STRAINER	1		
3	+	P005-004030	VALVE, INLET NEEDLE	1		
4	+	125338-13930	PIN, METERING ARM	1		
5	+	P005-000940	SPRING, METER. LEVER	1		
6	+	125323-08260	ARM, VALVE	1		
7	+	125339-42030	SCREW	1		
8	+	P005-000100	SCREW, THROTTLEADJUST	1		
9	+	125344-13931	SCREW	2		
10	+	P005-003760	DIAPHRAGM ,METERING	1		
11	+	P005-000200	GASKET, METERING	1		
12	+	125342-52130	COVER, DIAPHRAGM	1		
13	+	125344-52130	SCREW	2		
14	+	P005-000510	DIAPHRAGM, PUMP	1		
15	+	P005-000520	GASKET, PUMP	1		
16	+	P005-004020	BASE, ASY PRIMER	1		
17	+	P005-003110	PUMP, PRIMER	1		
18	+	P005-001250	RETAINER,PLUG BALL	1		
19	+	P005-001900	SCREW	4		
20	+	P005-000270	SCREW	1		
21	+	P005-001000	ROLLER, GUIDE	1		
22	+	P005-000250	RETAINER	1		
23	+	P005-004050	SCREW,MAIN MIXTURE	1		

FUEL TANK

KEY NO	LV(+)	Part No	Description	Qty	Standard	Comment
1		P100-001880	CAP ASY,TANK	1		
2	+	131016-55830	GASKET, FUEL CAP	1		
3	+	131051-56030	CLIP, FUEL CAP	1	100L	
4		132115-46730	GROMMET, FUEL	1		
5		V471-005240	PIPE	1	3*5*80	
6		V186-000520	JOINT,PIPE	1		
7		V471-003730	PIPE	1		
8		V490-001240	CLIP	1		
9		132010-49730	PIPE 3*6*85	1	3*6*85 YL	
10		V471-005250	PIPE	1	3*5*60	
11		A369-000470	STRAINER, FUEL	1		
12		V490-001240	CLIP	1		
13		A356-000031	VALVE,CHECK	1		
14		V490-001240	CLIP	1		


MUFFLER



MUFFLER

KEY NO	LV(+)	Part No	Description	Qty	Standard	Comment
1		P100-003840	MUFFLER ASY	1		
2	+	A310-000510	SCREEN, ARRESTOR	1	17*41.5	
3	+	V804-000030	BOLT, TORX 4	1	TB-4*8 10.9	
4		V104-002350	GASKET,EXHAUST	1	T1.0	
5		V805-000210	BOLT, TORX 5	2	TB-5*20 12.9	


RECOIL STARTER, PULLY



RECOIL STARTER, PULLY

KEY NO	LV(+)	Part No	Description	Qty	Standard	Comment
1		A051-003310	STARTER,RECOIL ASY	1		
2	+	P022-048990	STATER CASE	1		
3	++	P022-045770	GUIDE, ROPE	1		
4	+	P022-049000	REEL	1		
5	+	P022-019680	SPRING, SPIRAL	1		
6	+	177236-44330	SCREW	1		
7	+	P022-049010	ROPE,STARTER	1		
8	+	P022-036700	GRIP, STARTER	1		
9		177202-40630	PAWL ASSY, STARTER	1		
10	+	A514-000120	RACHET	1		
11	+	177234-40630	SPRING, RETURN	1		
12	+	P022-002100	E-RING	1	4	
13		A127-000510	COVER,DUST	1		
14		V805-000150	BOLT, TORX 5	3	TB-5*16 10.9	
15		X547-003230	LABEL,ECHO	1	ECHO+PB-2520	


FAN CASE



FAN CASE

KEY NO	LV(+)	Part No	Description	Qty	Standard	Comment
1		E103-001461	CASE,FAN	1	E-SIDE W/TANK	
2		V805-000150	BOLT, TORX 5	4	TB-5*16 10.9	
3		E100-000290	FAN,BLOWER	1		
4		V806-000010	BOLT, TORX 6	2	TB-6*20 10.9	
5		E103-001470	CASE,FAN	1		
6		E104-000270	GRID, BLOWER	1		
7		V805-000010	BOLT, TORX 5	7	TT-5*20 DG 10.9	
8		X505-009970	LABEL,CAUTION	1	ISO SYMBOL PB	


THROTTLE



THROTTLE

KEY NO	LV(+)	Part No	Description	Qty	Standard	Comment
1		P100-003830	SWITCH,ON OFF	1		
2		C450-000721	CONTROL, THROTTLE	1		
3		C454-000580	ROD, THROTTLE	1		
4		C453-000300	LEVER,THROTTLE	1		
5		900603-00005	WASHER 5	1	5.5*12*0.8	
6		V805-000220	BOLT, TORX 5	1	TB-5*25 12.9	
7		900605-00005	WASHER, SPRING 5	1	5	
8		900602-00005	WASHER 5	1	5.3*10*1	
9		900562-50005	LOCKNUT 5	1	5	
10		A190-001621	COVER,ENGINE	1		
11		V805-000010	BOLT, TORX 5	6	TT-5*20 DG 10.9	


PIPE



PIPE

KEY NO	LV(+)	Part No	Description	Qty	Standard	Comment
1		E165-000951	PIPE,BLOWER	1	S-SHAPE W/ GUARD	
2		E165-000880	PIPE,BLOWER	1		

ACCESSORIES



ACCESSORIES

KEY NO	LV(+)	Part No	Description	Qty	Standard	Comment
1		895410-06961	WRENCH, W/S-DRIVER	1	13X19 L135	

NUMERICAL PARTS INDEX

Part No	Part description	Page	Part No	Part description	Page	Part No	Part description	Page
100013-3-5430	PIN, PISTON	2	900800-3-6001	BEARING, BALL 6001	4	C450-00-0721	CONTROL, THROTTLE	20
100015-0-3931	CIRCLIP, PISTON PIN	2	900810-3-6000	BEARING, BALL	4	C453-00-0300	LEVER, THROTTLE	20
100142-1-2330	KEY, WOODRUFF	6	A011-00-1510	CRANKSHAFT, ASY	2	C454-00-0580	ROD, THROTTLE	20
100212-4-2031	OILSEAL	4	A021-00-4700	CARBURETOR, DIAPHRAGM	8	E100-00-0290	FAN, BLOWER	18
100212-6-1830	OILSEAL	4	A021-00-4700	CARBURETOR, DIAPHRAGM	10	E103-00-1461	CASE, FAN	18
125323-0-8260	ARM, VALVE	10	A051-00-3310	STARTER, RECOIL ASY	16	E103-00-1470	CASE, FAN	18
125338-1-3930	PIN, METERING ARM	10	A101-00-0720	RING, PISTON	2	E104-00-0270	GRID, BLOWER	18
125339-4-2030	SCREW	10	A127-00-0510	COVER, DUST	16	E165-00-0880	PIPE, BLOWER	22
125342-5-2130	COVER, DIAPHRAGM	10	A130-00-2340	CYLINDER	2	E165-00-0951	PIPE, BLOWER	22
125344-1-3931	SCREW	10	A190-00-1621	COVER, ENGINE	20	P005-00-0010	STRAINER	10
125344-5-2130	SCREW	10	A200-00-1130	INSULATOR, INTAKE	8	P005-00-0100	SCREW, THROTTLE ADJUST	10
131016-5-5830	GASKET, FUEL CAP	12	A226-00-2160	ELEMENT, AIR FILTER	8	P005-00-0200	GASKET, METERING	10
131051-5-6030	CLIP, FUEL CAP	12	A232-00-1920	LID, CLEANER	8	P005-00-0250	RETAINER	10
132010-4-9730	PIPE 3*6*85	12	A244-00-0330	PLATE, PREVENT	8	P005-00-0270	SCREW	10
132115-4-6730	GROMMET, FUEL	12	A259-00-0010	CAP, LIMITER	8	P005-00-0510	DIAPHRAGM, PUMP	10
177202-4-0630	PAWL ASSY, STARTER	16	A310-00-0510	SCREEN, ARRESTOR	14	P005-00-0520	GASKET, PUMP	10
177234-4-0630	SPRING, RETURN	16	A356-00-0031	VALVE, CHECK	12	P005-00-0940	SPRING, METER. LEVER	10
177236-4-4330	SCREW	16	A369-00-0470	STRAINER, FUEL	12	P005-00-1000	ROLLER, GUIDE	10
895410-0-6961	WRENCH, W/S-DRIVER	24	A409-00-1320	ROTOR, MAGNETO	6	P005-00-1250	RETAINER, PLUG BALL	10
900515-0-0008	NUT, FLANGE 8	6	A411-00-1750	COIL, IGNITION	6	P005-00-1900	SCREW	10
900562-5-0005	LOCKNUT 5	20	A425-00-0000	SPARKPLUG	6	P005-00-3110	PUMP, PRIMER	10
900602-0-0005	WASHER 5	20	A426-00-0010	TERMINAL, SPARKPLUG	6	P005-00-3760	DIAPHRAGM, METERING	10
900603-0-0005	WASHER 5	20	A427-00-0013	CAP, SPARK PLUG	6	P005-00-4020	BASE, ASY PRIMER	10
900605-0-0005	WASHER, SPRING 5	20	A514-00-0120	RACHET	16	P005-00-4030	VALVE, INLET NEEDLE	10

NUMERICAL PARTS INDEX

Part No	Part description	Page	Part No	Part description	Page
P005-00-4050	SCREW,MAIN MIXTURE	10	V471-00-5250	PIPE	12
P022-00-2100	E-RING	16	V490-00-1240	CLIP	12
P022-01-9680	SPRING, SPIRAL	16	V554-00-0030	BEARING,NEEDLE 9	2
P022-03-6700	GRIP, STARTER	16	V804-00-0030	BOLT, TORX 4	14
P022-04-5770	GUIDE, ROPE	16	V805-00-0010	BOLT, TORX 5	18
P022-04-8990	STATER CASE	16	V805-00-0010	BOLT, TORX 5	20
P022-04-9000	REEL	16	V805-00-0100	BOLT, TORX 5	8
P022-04-9010	ROPE,STARTER	16	V805-00-0150	BOLT, TORX 5	16
P100-00-1880	CAP ASY,TANK	12	V805-00-0150	BOLT, TORX 5	18
P100-00-3800	PISTON KIT	2	V805-00-0210	BOLT, TORX 5	2
P100-00-3810	CRANK CASE SET	4	V805-00-0210	BOLT, TORX 5	6
P100-00-3820	CASE,CLEANER	8	V805-00-0210	BOLT, TORX 5	8
P100-00-3830	SWITCH,ON OFF	20	V805-00-0210	BOLT, TORX 5	14
P100-00-3840	MUFFLER ASY	14	V805-00-0220	BOLT, TORX 5	4
V100-00-0860	GASKET,CYL	2	V805-00-0220	BOLT, TORX 5	20
V102-00-0300	GASKET, CRANKCASE	4	V806-00-0010	BOLT, TORX 6	18
V103-00-1950	GASKET,INTAKE	8	X505-00-9970	LABEL,CAUTION	18
V103-00-1960	GASKET,INTAKE	8	X547-00-3230	LABEL,ECHO	16
V104-00-2350	GASKET,EXHAUST	14			
V186-00-0520	JOINT,PIPE	12			
V306-00-0520	WASHER,CIRCULAR 8	2			
V323-00-0070	WASHER,CIRCULAR 5	6			
V471-00-3730	PIPE	12			
V471-00-5240	PIPE	12			