



PARTS LIST

SHORT REACH TRIMMER

SRTZ2600

NOTE :

1. Use ZENOAH genuine parts as specified in the parts list for repair and/or replacement.
2. ZENOAH does not warrant the machines, which have been damaged by the use of any parts other than those specified by the company.
3. When placing parts orders for repair and/or replacement, check if the model name and the serial number are applicable to those specified in the parts list, then use parts number described in the parts list.
4. The contents described in the parts list are accurate as of the date and may change due to improvement.
5. The parts for the machine shall be supplied ten (10) years after the machine is discontinued. [It is possible that some specific parts may be subject to change of their delivery term and list price within the limit of ten (10) years after the machine is discontinued. It is also possible that some parts may be available even after the limit of ten (10) years.]

APPLICABLE SERIAL NUMBERS:

000101 and up

April 2005

Fig.1 DRIVE UNIT




Fig.2 CUTTING UNIT




Fig.1 DRIVE UNIT

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	T3075-12100	PIPE COMP.	1		21	3540-91120	• SPANNER	1	
2	T3075-12210	SHAFT	1		22	3540-91110	• BAR	1	
3	T3076-11330	GRIP ASSY	1						
4	6420-17300	HANGER ASSY	1						
5	6420-17400	• HANGER COMP.	1						
6	9366-17110	•• HANGER	1						
7	9366-17120	•• CLAMP	1						
8	6420-17410	•• SLEEVE	1						
9	0263-90525	• SCREW	1						
10	T3076-12510	NAME-PLATE	1						
11	3436-91170	CAUTION-PLATE	1						
12	6489-14000	HANDLE ASSY	1						
14	6420-14320	• CLAMP	1						
15	0263-90535	• SCREW	4						
16	T3300-17100	STRAP ASSY	1						
17	T3002-91000	TOOL-SET	1						
18	1030-91340	• DRIVER	1						
19	T3002-91310	• SOCKET	1						
20	09007-00425	• WRENCH	1						

Fig.2 CUTTING UNIT

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	6598-13110	LEVER, clamp	1		46	6598-13620	O-RING	1	P41
2	0290-20615	WASHER	1	M6	47	04065-02612	SNAP RING	1	
3	6782-13650	WASHER	1	6x16x2.0	48	06004-06000	BEARING	1	
4	6782-13141	ANGLE ADJUSTER	1		49	6780-13710	CASING B	1	
5	0225-10612	BOLT	2	M6x12	50	6782-13650	WASHER	1	
6	6782-13200	CASING A SET	1		51	0225-10612	BOLT	1	M6x12
7	—	• CASING A	1		52	6782-13720	WASHER	1	5x10x1.0
8	6782-13220	• PLATE	1		53	01252-30510	BOLT	1	M5x10
9	3199-13350	GREASE FITTING	3		54	3350-21320	BOLT	1	M5x30
10	T3078-13250	LABEL	1		55	6782-13810	JOINT	1	
11	0263-10408	SCREW	2	M4x8	56	6598-13820	GEAR SHAFT B	1	
12	6598-13320	COVER	1		57	6782-13830	BEARING	2	6900RS
13	6598-13330	SNAP RING	1		58	04065-02212	SNAP RING	1	
14	6782-13340	BEBEL GEAR	1		59	6782-13850	BEVEL GEAR	1	
15	04065-02612	SNAP RING	1		60	6598-13330	SNAP RING	1	
16	06004-06000	BEARING	1		61	6598-13860	PACKING	1	
17	6782-13370	CRANK SHAFT	1		62	6598-13871	PLATE	1	
18	04064-02815	SNAP RING	1		63	0263-10410	SCREW	2	M4x10
19	T3078-13410	BLADE	2		64	T3078-13910	BLADE COVER	1	
20	6782-13430	BEARING	1	608Z	65	6782-06010	COVER SET	1	
					66	6782-13441	• COVER	1	
23	6782-13460	FELT	1		67	6782-13470	• GASKET	1	
24	3884-11750-10	SCREW	1		68	6783-13450	• BOLT	4	M4x12
25	3880-11780	WASHER	6						
26	6598-13510	SCREW	5	L17					
27	6598-13530	SCREW	2	M5x20					
28	T3078-13540	GUIDE PLATE	1						
29	6782-13550	PLATE	1						
30	6782-14470	NUT	2	M5					
31	3880-11790	NUT	6	M6					
32	6782-13650	WASHER	1	6x15x2.0					
33	6598-13430	BEARING	1	608 2RS					
34	04065-02212	SNAP RING	1						
35	T4008-06010	SHAFT KIT	1						
44	0280-10605	• NUT	1	M6					
45	0290-20615	WASHER	1						


Fig.3 ENGINE UNIT

Fig.3 ENGINE UNIT

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	848F3012A2	CYLINDER	1		75	5500-81160	• WASHER	1	
2	4810-12210	GASKET, base	1		76	0263-90560	SCREW	2	M5x60
3	1850-12130	BOLT	2	M5x22	77	4810-15100	MUFFLER ASSY	1	
4	4810-13162	INSULATOR	1						
5	4810-13120	GASKET, insulator	1		79	4810-15140	• ARRESTER	1	
6	4810-13130	GASKET, carburetor	1		80	01252-30550	BOLT	2	M5x50
7	0263-90520	SCREW	2	M5x20	81	T1501-15211	GASKET	1	
8	848F301602	REEDVALVE (S) ASSY	1		82	4810-31002	COVER ASSY	1	
					83	4810-31102	• COVER COMP.	1	
10	4810-16120	• REEDVALVE	1		84	4810-31111	•• COVER, fan	1	
11	4810-16130	• STOPPER	1		85	848F3051A1	•• DRUM	1	
12	4810-16170	• SCREW	1	M3x8	86	04065-02812	•• SNAPRING	1	
13	4810-16150	PIRE AIR (S)	1		87	T1701-31150	•• BEARING	1	
14	848F301612	REEDVALVE (F) ASSY	1		88	04064-01210	•• SNAP RING	1	
					89	6470-31211	• BRACKET (A)	1	
16	4810-16120	• REEDVALVE	1		90	6470-31221	• BRACKET (B)	1	
17	4810-16130	• STOPPER	1		91	6470-31230	• CUSHION	1	
18	4810-16170	• SCREW	1	M3x8	92	01252-30530	• BOLT	2	M5x30
19	4810-16160	PIPE AIR (F)	1		93	01252-30514	• BOLT	1	M5x14
20	4810-16140	GASKET, valve	2		94	5500-85510	SCREW	1	M5x16
21	4810-16180	SCREW	6		95	0263-90520	SCREW	4	M5x20
22	4810-21101	CRANKCASE COMP.	1		96	4810-32111	COVER, engine	1	
23	2629-21130	• PIN	3		97	T1501-12310	PLATE	1	
24	4810-21140	GASKET	1		98	0263-90510	SCREW	2	M5x10
25	06030-06001	BEARING	2		99	4820-51110	SHOE	2	
26	4810-21210	SEAL	1		100	4820-51220	SPRING	1	
27	1850-21220	SEAL	1		101	1140-51250	SCREW	2	
28	04065-02812	SNAP RING	1		102	1140-51230	WASHER	2	
29	01252-30530	BOLT	3	M5x30	103	1140-51242	WASHER	2	
					104	4810-72111	CAP	1	
32	4810-41110	PISTON	1		105	1900-72120	SPRING	1	
33	5910-41210	RING	2		106	4810-71240	CORD	1	
34	T1513-41310	PIN	1		107	4810-71250	CORD, earth	1	
35	1260-41320	RING	2		108	T1512-71320	TUBE	1	
36	5500-41410	BEARING	1		109	3699-91667	PLUG	1	
37	1101-41340	WASHER	2		110	4810-72120	GROMMET	1	
38	4810-42000	CRANKSHAFT COMP.	1		111	4810-75100	RECOIL ASSY	1	
39	1650-43230	NUT	1		112	4500-75120	• REEL	1	
40	1000-43240	KEY	1		113	4500-75150	• SCREW	1	
41	4810-71110	ROTOR	1		114	1850-75130	• SPRING, spiral	1	
42	T1501-71200	COIL ASSY	1		115	4500-75180	• COLLAR	1	
43	T1512-71220	• CORD	1		116	4500-75190	• ARM	1	
44	2616-71320	• CAP	1		117	4810-75160	• ROPE	1	
45	1260-71261	SPACER	2		118	3330-75421	• KNOB	1	
46	4500-72150	BOLT	2	M4x22	119	4810-75170	• PLATE, stopper	1	
47	848F308103	CARBURETOR ASSY	1		120	4500-75210	PULLEY	1	
48	T1551-06030	• REBUILD KIT	1		121	5500-85510	SCREW	2	M5x16
49	T1551-81450	•• BODY ASSY	1		122	4810-82100	BODY ASSY	1	
50	_____	••• SCREEN	—		123	4810-82130	• PLATE, choke	1	
51	_____	••• VALVE	—		124	5500-82140	• LEVER, choke	1	
52	_____	••• SPRING	—		125	2630-33610	• SCREW	1	
53	_____	••• SCREW	—		126	4810-82170	ELEMENT	1	
54	_____	••• PIN	—		127	4810-82180	SCREEN	1	
55	_____	••• LEVER	—		128	4810-82200	COVER ASSY	1	
56	4810-06021	•• GASKET KIT	1		129	5500-82221	• KNOB	1	
57	_____	••• DIAPHRAGM	—						
58	_____	••• GASKET, diaphragm	—		130	T1504-85002	TANK ASSY	1	
59	_____	••• DIAPHRAGM, pump	—		131	T1015-85202	• CAP ASSY	1	
60	_____	••• GASKET, pump	—		132	4500-85300	•• HOLDER ASSY	1	
61	_____	••• RING	—		133	4500-85220	•• PACKING	1	
62	1850-81490	• BODY, purge	1		134	5601-85260	•• FILTER	1	
63	1850-81520	• COVER, pump	1		135	4820-85260	•• STOPPER	1	
64	1751-81510	• PUMP, priming	1		136	4810-85300	• PIPE COMP.	1	
65	T1505-81250	• JET	1		137	3302-85400	• FLTER ASSY	1	
66	1751-81240	• O-RING	1		138	2841-31280	• COLLAR	1	
67	1751-81130	• RING	1						
68	1881-81140	• SWIVEL	1		140	5500-85510	SCREW	3	M5x16
69	_____	• VALVE ASSY	—		141	T1504-75410	LABEL, recoil	1	
70	1752-81110	• SCREW	2		142	T1504-31130	LABEL, cover	1	
71	5500-81120	• BRACKET	1		143	T1506-31910	GUARD	1	
72	1751-81180	• NUT, adjuster	1		144	0263-90525	SCREW	2	
73	1918-81170	• SCREW, adjuster	1		145	1950-86120	CLIP	1	
74	1850-81530	• SCREW	4						